A-C FULL VOLTAGE–MAGNETIC

Price Additions for Optional Features

Item	Description	NEMA SIZE 00	0	1	2	3	4	5	6-7-8
	Enclosures								
1	Start, Stop Pushbutton or Run-Off-Auto Selector Switch in cover of NEMA 1	$8.	$8.	$8.	$8.	$8.	$8.	$8.	$33.
	All other enclosures	---	22.	22.	22.	22.	22.	22.	50.
2	Pilot light in cover of NEMA 1	---	15.	15.	15.	15.	15.	15.	27.
	All other enclosures	---	27.	27.	27.	27.	27.	27.	27.
3	Breather and Drain in NEMA 7 and 9	---	6.	6.	6.	6.	6.	6.	---
4	Forward, Reverse, Stop Pushbuttons in cover of NEMA 1	---	40.	40.	40.	40.	40.	40.	57.
	NEMA 4, 5-12 and 9	---	50.	50.	50.	50.	50.	50.	67.
5	Size 0, cast aluminum, NEMA 4; with 2 Coil Overload Relay:								
	Cat. No. 9586H6018—Reset Button in cover	---	N/C	---	---	---	---	---	---
	9586H6019—Start, Stop Pushbuttons in cover	---	N/C	---	---	---	---	---	---
	9586H6020—Run-Off-Auto Selector Switch in cover	---	N/C	---	---	---	---	---	---
	Size 1, cast aluminum, NEMA 4; with 2 Coil Overload Relay:								
	Cat. No. 9586H6131—Reset Button in cover	---	---	N/C	---	---	---	---	---
	9586H6132—Start, Stop Pushbutton in cover	---	---	N/C	---	---	---	---	---
	9586H6133—Run-Off-Auto Selector Switch in cover	---	---	N/C	---	---	---	---	---
	Panel Equipment								
6	❶ Control Circuit Transformer—Single and Dual Voltage Primary, 60 or 50 cycles	---	27.	27.	38.	56.	68.	77.	77.
	25 cycles	---	41.	41.	57.	84.	102.	102.	102.
	With 100 watt extra capacity, 60 or 50 cycles	---	48.	48.	62.	78.	88.	98.	98.
	25 cycles	---	72.	72.	93.	117.	132.	147.	147.
	With 200 watt extra capacity, 60 or 50 cycles	---	65.	65.	81.	97.	107.	107.	---
	With 300 watt extra capacity, 60 or 50 cycles	---	82.	82.	100.	116.	126.	126.	---
7	Separate Control Circuit	---	---	N/C	N/C	N/C	N/C	N/C	N/C
8	Substitute Dual Voltage Coil — Per coil	---	2.	2.	2.	2.	2.	2.	---
9	Substitute Special Voltage or Frequency Magnet Coil — Per coil	3.	3.	4.	5.	7.	8.	10.	11.
	Standard Voltages 110, 115, 120, 208, 220, 230, 240, 277, 380 (50 cycles), 440, 460, 480, 550, 600 **Standard Frequencies** 25, 50, 60 cycles								
	Overload Relay								
10	Standard Duty and Fast Trip Overload Heater Coils, Addition or Deduction Each coil	1.50	1.50	1.50	1 50	1.50	1.50	1.50	1.50
11	3 Coil Overload Relay with Standard Trip Heater Coil	4.	4.	4.	4.	4.	4.	40.	70.
12	Substitute Fast Trip for Standard Trip Overload Relay	N/C	N/C	N/C	N/C	N/C	N/C	N/C	N/C
13	Substitute Automatic Reset for Manual Reset	N/C	N/C	N/C	N/C	N/C	N/C	N/C	N/C
14	Thermal Overload Relay with Normally Open Contacts, or Normally Open and Normally Closed Contacts	4.	4.	4.	4.	4.	4.	4.	4.
	Auxiliary Contacts								
15	Auxiliary Contacts—For Field Installation				See Table Below				
16	Extra Auxiliary Contacts—Factory Installed								
	Normally Open or Normally Closed	---	11.	11.	11.	11.	11.	11.	33.
	Normally Open and Normally Closed	---	22.	22.	---	---	---	---	---

AUXILIARY CONTACT KITS

Contacts	Catalog Numbers Size 0	Size 1	Size 2	Size 3	Size 4 & 5	Price
Normally Open	10933-H1	10933-H1	10933-H7	10933-H7	10933-H7	$6.
Normally Closed	H2	H3	H8	H9	H21	6
Normally Closed Late Opening	H4	H4	H10	H10	H10	6.
Normally Open & ❸ Normally Closed	H5	H6	---	---	---	8.

MAXIMUM NUMBER OF EXTRA AUXILIARY CONTACTS PER CONTACTOR

Catalog No.	Size 0 & 1	Size 2 & 3	Size 4 & 5
9586	2	3	4
9589 & 9591	2	3	3
9656	1	2	3
9658 & 9659	1	2	2

A maximum of two normally closed contacts may be added per contactor.
Only one normally closed late opening contact is permissible per contactor.

❶ Transformers in NEMA 1, 4, 5 or 12 enclosures have fused secondary.

❸ Both normally open and normally closed contacts must be used on the same side of the line.

DISCOUNT SCHEDULE **ICD**