

S.V. 200, 202, 204, 210, 213, 261, 264 C.V.

CG 18 CODE GT-751-D PRG.

JUL 16 80 36544
EST. WGT. 2350 LBS.

STD. HRS. TIME 11P M

D.V.

PROCESSES		APPROVED BY	
()	GT-751-D P)	AJC	05-09-77
()	GT-829-D (A)	MTW	05-16-77
()	()	DCG	05-18-77
()	()		
TYPED BY			
emw051977			

#2
STATION

JUL 17 1980

NON-BLEEDING

QUIPMENT	NAME:	USE LBS.	N CODE	ACCT LBS.
SV	MONASTRAL® GREEN G			
2	Run 2-3" (±200 G) water into V-			
	Use station # 2, preset water meter per chart for water addition to full totes. Use mode 3 for N-8101-A, when 8104-A used instead use mode 4, & pump in ±2300# 100% to the nearest tote		8101-A	
	Gals of Water			
	Sequencer Steps			
	LOT 6 11 16 #100% %			
	819-B 100 20 75 641 23.3 2750 8101-A 641			
	807-B 100 20 100 870 34.8 2500 8101-A 870			
	807-A 100 20 100 872 34.9 2500 8101-A 872			
	2383 #100% Total		8101-A	
3	After last tote pumped, run in 100 gals of water & pump to clean system			
4	Start agitator & stir 5 min			
5	Record: pH 7.0 (6.5-7.5)			
6	If above pH 7.5, adj to pH 6.0-7.5			
	NOTE: Add N-30-D 1 to 2# at a time using the minimum total amount of N-30-D			
	Record: pH 6.7	M 9.2908%	10	30-D 8
	Flood to 8.2			
	Stop agitator			
Misc	Calc: Est Wgt			
	2323#100% N-8101-A &/or N-8104-A x 0.986 = 2350# Est			
10	Record on make & process cards			
SV	200 202 204 210 213 261 264			
S 7	54" 62" 62" 53" 37" 42" 82"			
Gal	3650 3670 3646 3684 3667 3654 3624			
	START 12:32 AM 2:00 PM 4:05 PM			
	FIN			
	OPTR 348 144			