



Interoffice Communication

To Laboratory Analyst
From Alan Hart
Date June 7, 1979
Subject Sampling Handling

A passive dosimeter monitoring system is being tested this summer. The employees on the dosimeter testing schedule will be asked to wear four badge monitors in addition to the charcoal tube and Sipin pump dosimeter. The badges must be validated against the charcoal tube system. The badges should be clipped to the employee's collar in the breathing zone. When the employee returns to turn in the dosimeters, write the Sipin pump number, employee name and date on a tag. Attach the tag to each badge, seal each badge in a zip lock bag. Put all the zip lock bags with badges into a single bag, seal and refrigerate.

A handwritten signature in cursive script that reads "Alan Hart".

Alan Hart

br

VVC 000008742

625 3431

309- W. Lee Street

Maplewood - off Citrus Senior Highway
behind Market basket

Moving Back Aug 21 =