

occasionally the engineer is confronted with the problem of removing such material before the air in question is suitable for use in building ventilation.

The physical properties of the particulate impurities of air are summarized conveniently in the chart of Fig. 1.

In the case of gases, the objectionable features are the injurious physiological effects and the danger from inflammability. (See Table 1.)

Dust Concentrations

It is customary to report dust concentrations as grains per 1000 cu ft or milligrams per cubic meter (except for dusts that may cause pneumoconiosis, which are reported as so many particles per cubic foot of air). Gas concentrations are commonly recorded as milligrams per cubic meter or as parts per million or as per cent by volume. Typical ranges in dust concentrations as now found in practical applications are given in Table 2.

TABLE 2. DUST CONCENTRATION RANGES IN PRACTICAL APPLICATIONS^a

APPLICATION	GRAINS PER 1000 CU FT	MGS PER CU M
Rural and suburban districts.....	0.2 to 0.4	0.4 to 0.8
Metropolitan districts.....	0.4 to 0.8	0.9 to 1.8
Industrial districts.....	0.8 to 1.5	1.8 to 3.5
Dusty factories or mines.....	4.0 to 80.0	10 to 200
Explosive concentrations (as of flour or soft coal).....	4000 to 8000	10,000 to 20,000

^a 1 grain per 1000 cu ft = 2.3 mgs per cubic meter; 1 oz per cubic foot = 1 g per liter.

The engineer frequently desires information regarding the effects of various concentrations of gases or dusts upon man, as the success of a particular installation may depend upon the maintenance of air which is adequately clean. At the present time there are several organizations working on this problem all of them publishing literature of various kinds.¹ References to books covering the hygienic significance, determination and control of dust are listed at the end of this chapter.

AIR POLLUTION AND HEALTH

The prevention of various diseases which result from exposure to atmospheric impurities is an engineering problem. It is important for the engineer to insure, by proper ventilation, suitable environments for working or for general living. If the equipment used is to be successful, it must operate automatically as in the modern air conditioned theater or railroad train.

In Table 3 are given data on permissible accepted standards for toxicity of gases and vapors which occur in industry. The prudent engineer will design equipment using these bench marks as the upper limits of pollution. In general it is good practice to avoid recirculation of air which originally contains toxic substances. Obviously there may be

¹National Institute for Health, U.S. Public Health Service; Division of Labor Standards, U. S. Department of Labor; University of Toronto Medical School, Canada; Saranac Laboratories, Saranac Lake, N. Y.; Industrial Hygiene Foundation, Inc., Pittsburgh, Pa.; Harvard School of Public Health, Boston, Mass.; Haskell Laboratory, Wilmington, Del.; and the Departments of Health and of Labor in the United States and in various provinces of Canada.

exceptions to this rule, but it is one which is generally being followed in current practice.

Affections of the respiratory tract are associated with exposure to thick dust, and may follow inhalation of practically any kind of insoluble and non-colloidal dust. Atmospheric dust in itself cannot be blamed for

TABLE 3. ACCEPTED STANDARDS FOR TOXICITY OF GASES AND VAPORS^a

SUBSTANCE	SINGLE EXPOSURES			MAX. ALLOWABLE AVERAGE CONCENTRATION FOR REPEATED EXPOSURES
	Rapidly Fatal (ppm)	Dangerous for from 1/2 to 1 Hour (ppm)	Max. Safe Concentration for 1/2 to 1 Hour (ppm)	
Ammonia.....	5,000-10,000	2500	300	100
Amyl acetate.....	-----	-----	105-160	400
Aniline.....	250	15	6	5
Arsine.....	190	-----	31-47	100
Benzene.....	-----	-----	-----	400
Butyl acetate.....	4800	3200-3850	960-1600	20
Carbon bisulfide.....	80,000-100,000	-----	-----	100
Carbon dioxide.....	4000	1500-2000	400	100
Carbon monoxide.....	10,000	-----	1000	1
Carbon tetrachloride.....	900	14-21	3.5	75
Chlorine.....	-----	-----	-----	15
Dichlorobenzene.....	-----	-----	-----	400
Dichlorethyl ether.....	-----	-----	-----	100
Ether.....	-----	-----	-----	20
Ethylene dichloride.....	-----	-----	-----	1000
Formaldehyde.....	-----	-----	-----	10
Gasoline.....	-----	-----	-----	20
Hydrochloric acid.....	270	110-135	45-54	10
Hydrogen cyanide.....	1250-1750	1000-1350	40-90	3
Hydrogen chloride.....	660	50-250	10	20
Hydrogen fluoride.....	1000-2000	360-500	200-300	200
Hydrogen sulfide.....	-----	-----	-----	-----
Methanol.....	20,000-40,000	2000-4000	1000	5
Methyl bromide.....	150,000-300,000	20,000-40,000	7000	10
Methyl chloride.....	-----	-----	200	1
Nitrobenzene.....	320-530	117-154	-----	2
Oxides of nitrogen.....	90	12.5	-----	10
Phosgene.....	2000	400-600	100-200	10
Phosphine.....	400-500	150-190	50-100	10
Sulfur dioxide.....	7300	-----	-----	200
Tetrachlorethane.....	-----	-----	-----	200
Tetrachlorethylene.....	-----	-----	-----	200
Toluene and xylene.....	-----	-----	3700	200
Trichlorethylene.....	7800	-----	-----	200
Turpentine.....	-----	-----	-----	-----

^aAdapted from The Prevention of Occupational Diseases, by R. R. Sayers and J. M. Dalla Valle (Mechanical Engineering, Vol. 57, No. 4, April, 1935); Safe Concentrations of Certain Common Toxic Substances used in Industry, by M. Bowditch, C. K. Drinker, P. Drinker, H. A. Haggard and H. Hamilton (Journal of Industrial Hygiene and Toxicology, Vol. 22, No. 6, June, 1940); and other authoritative sources.

causing tuberculosis, but it may aggravate the disease once it has started.²

The sulphurous fumes and tarry matter in smoke are more dangerous than the carbon. In foggy weather the accumulation of these substances in the lower strata may be such as to cause irritation of the eyes, nose, and respiratory passages. The Meuse Valley fog disaster will probably become

²Physiological Response of the Peritoneal Tissue to Dusts Introduced as Foreign Bodies, by Miller and Sayers (U. S. Public Health Reports, 49:80, 1934).