

SHIPPING LOT NUMBERS

Shipping lot numbers follow the same basic form as the CPC plant process batch numbers. The general form is as follows: (y-ddd-##) where y=the last digit of the current year, ddd=the julian number for the date the trailer is loaded, and ## is the number of shipments made in the current year.

For example, a trailer loaded on January 2, 1987 would be assigned a lot number of 7-002-3 if it was the third trailer loaded in 1987. A trailer loaded on December 31st, 1986 would be assigned a lot number of 6-365-32 if it were the 32nd trailer loaded in 1986.

This number should be put on the sample sent to the lab for the certificate of analysis and also recorded on the CPC shipment sheet.

CONFIDENTIAL:
Subject to Protective Order
of 14th Judicial District Court
No. 91-1145

SL 001364