

from

J. C. LUNN, Jr.

7 SEPT, 1972

To JRH

Attached are the special blending instructions to be used for lots No. 129, 55 and 57 in the 91" 100% Catalyst layer in R-303.

Cris

cc: RHG, RDG, JDM, DCS, RWC, GTH, HDA(2)

SPECIAL R-303 91" 100% CATALYST BLEND

① BLEND
 1 DRUM LOT 129
 +
 1 DRUM LOT 55 } → 2 DRUMS ~ 17.92% Cu

② BLEND
 1 DRUM LOT 129
 +
 1 DRUM LOT 57 } → 2 DRUMS ~ 17.98% Cu

③ BLEND
 1 DRUM LOT 129
 +
 1 DRUM ~ 17.92% Cu } → 2 DRUMS ~ 18.43% Cu

④ BLEND
 1 DRUM LOT 129
 +
 1 DRUM ~ 17.98% Cu } → 2 DRUMS ~ 18.46% Cu

LABLE AS
 SPECIAL
 100% BLEND
 FOR R-303
 91" CATALYST
 LAYER

⑤ REPEAT STEPS ③ AND ④ ONCE .

CCR 000034194

CONTINENTAL OIL COMPANY
 CALCULATION SHEET

JOB NO. _____

TITLE R-303 100% SPECIAL BLEND

STATE _____