

HYDRAULIC BRAKE LINE APPLICATION (Cont.)

Car & Years	Models	Master Cylinder to Main Connector Line		L E N G T H	Connector to Left Front Brake Hose Line	L E N G T H	Connector to Right Front Brake Hose Line	L E N G T H	Main Connector to Front Connector	L E N G T H	Master Cylinder or Main Connector to Rear Brake Hose	L E N G T H	Rear Brake Hose to Left Rear Brake	L E N G T H	Rear Brake Hose to Right Rear Brake	L E N G T H
		Front or Left	Rear or Right													
CHEVY II (Cont.)																
1966	All	3-6807	-	A/R	3-6826	A/R	3-6826	A/R	3-6810 & 3-6806	A/R	3-6805 & 3-6804	A/R	3-6803	A/R	3-6802	A/R
63-65	All	3-6807	-	19"	3-6826	8"	3-6809	76"	-	-	3-6805	118"	3-6802	26"	3-6803	34"
CHRYSLER (SEE IMPERIAL)																
67-68	All (Ex. Disc Brakes)	3-6802	3-6802	A/R	3-6803	A/R	3-6804	A/R	-	-	3-6805 & 3-6801	A/R	3-6802	A/R	3-6804	A/R
67-68	All w/Disc Brakes	3-6803	3-6802	A/R	3-6800	A/R	3-6805 & 3-6800	A/R	-	-	3-6805 & 3-6801	A/R	3-6802	A/R	3-6804	A/R
1966	All	3-6808	-	A/R	3-6803	A/R	3-6804	A/R	-	-	3-6805 & 3-6801	A/R	3-6802	A/R	3-6804	A/R
64-65	All	3-6802	-	21"	3-6800	12"	3-6805	60"	-	-	3-6805 & 3-6803	156"	3-6801	20"	3-6804	50"
61-63	All	3-6802	-	21"	3-6800	12"	3-6805	60"	-	-	3-6805 & 3-6802	148"	3-6801	20"	3-6804	50"
1960	All	3-6801	-	16"	3-6800	10"	3-6804	50"	-	-	3-6805 & 3-6802	148"	3-6802	22"	3-6804	45"
1959	All	3-6801	-	16"	3-6800	10"	3-6804	50"	-	-	3-6805 & 3-6800	130"	3-6802	22"	3-6804	45"
1958	All	-	-	-	3-6801	15"	3-6804	48"	-	-	3-6805 & 3-6800	130"	3-6801	19"	3-6803	32"
55-57	All	-	-	-	3-6801	15"	3-6804	48"	-	-	3-6805 & 3-6826	127"	3-6801	19"	3-6803	32"
COMET																
67-68	All	3-6801	3-6801	A/R	3-6802	A/R	3-6801	A/R	3-6805	A/R	3-6804 & 3-6805	A/R	3-6804	A/R	3-6802	A/R
1966	All	3-6805	-	A/R	3-6802	A/R	3-6801	A/R	-	-	3-6805	A/R	3-6804	A/R	3-6802	A/R
63-65	All	-	-	-	3-6802	28"	3-6804	50"	-	-	3-6805	120"	3-6801	20"	3-6803	40"
60-62	All	-	-	-	3-6802	23"	3-6805	57"	-	-	3-6805	120"	3-6801	20"	3-6804	41"
CORVAIR																
67-68	All	-	3-6806	A/R	3-6803	A/R	3-6804	A/R	3-6806 (F) & 3-6807 (R)	A/R	3-6811 & 3-6809	A/R	3-6826	A/R	3-6804	A/R
1966	All	3-6806	-	A/R	3-6803	A/R	3-6804	A/R	-	-	3-6811 & 3-6809	A/R	3-6826	A/R	3-6804	A/R
60-65	All	3-6806	-	12"	3-6827	10"	3-6810	45"	-	-	3-6804 & 3-6805	107"	3-6801	19"	3-6803	40"
CORVETTE																
67-68	All	3-6806	3-6806	A/R	3-6826	A/R	3-6804 & 3-6800	A/R	3-6808 (L/F)	A/R	3-6811 & 3-6808	A/R	3-6801	A/R	3-6801	A/R
1966	All	3-6809	-	A/R	3-6826	A/R	3-6804 & 3-6800	A/R	-	-	3-6811 & 3-6808	A/R	3-6801	A/R	3-6804	A/R
1965	All	3-6809	-	40"	3-6825	5"	3-6811	60"	-	-	3-6804 & 3-6803	89"	3-6801	20"	3-6801	20"
63-64	All	3-6809	-	40"	3-6825	5"	3-6811	60"	-	-	3-6804 & 3-6803	89"	3-6800	11"	3-6800	12"
56-62	All	3-6808	-	30"	3-6825	6"	3-6826	7"	3-6811 & 3-6807	76"	3-6805 & 3-6804	104"	3-6804	44"	3-6802	24"

A/R. As Required.

♦ For Rear Crossover Line in 1965 Use 3-6803 (Length 34"); 63-64 Use 3-6804 (Length 43").