

enclosure. Whenever possible, the asbestos should be removed and placed directly into bags for disposal rather than dropping the material to the floor and picking up all of the material when the removal is complete. If a significant amount of time elapses between the time that the material is removed and the time it is bagged, the asbestos material is likely to dry out and generate asbestos-laden dust when it is disturbed by people working within the enclosure. Any asbestos-

contaminated supplies and equipment that cannot be decontaminated should be disposed of in pre-labeled bags. Items in this category include plastic sheeting, disposable work clothing, respirator cartridges, and contaminated wash water.

A checklist is one of the most effective methods of ensuring adequate surveillance of the integrity of the asbestos removal enclosure. Such a checklist is shown in Figure F-6. Filling out the checklist at the beginning

of each shift in which asbestos removal is being performed will serve to document that all the necessary precautions will be taken during the asbestos removal work. The checklist contains entries for ensuring that:

- The work area enclosure is complete;
- The negative-pressure system is in operation;
- Necessary signs and labels are used;

BILLING CODE 4510-26-M