

580-STARTER POST ASSEMBLY (Cont.)

Car	Years	Models	Balkamp No.
DESOTO	57-59	All F'sweep	3-1288
DODGE	1960	Canada	3-1288
	57-59	All	3-1288
	1956	All w/P.F.	3-1287
	1955	All	3-1287
DODGE TRUCK	57-59	All 8 & 6 Cyl.	3-1288
	1956	All 8 Cyl.	3-1287
	1955	All 8 Cyl.	3-1287
	1955	Late 6 Cyl.	3-1287
FALCON	60-61	All	3-1286
FORD (See Falcon, Thunderbird)	62-64	All (Ex. Fairlane)	3-1285
	1962	Fairlane	3-1286
	1961	All 6 & 8 Cyl.	3-1285
	59-60	All 6 & 8 Cyl. 430"	3-1285
	56-58	All 6 & 8 Cyl.	3-1285
FORD TRUCK	61-63	Econoline	3-1286
	56-63	All 6 & 8 Cyl. 100-350	3-1285
HUDSON	1956	Hornet 6 Cyl. w/Std. Trans. & H.M.	3-1287
	1955	Hornet 6 Cyl. w/H.M.	3-1287
KAISER & FRAZER	54-56	A.L. Equip.	3-1287
LINCOLN	61-63	All	3-1286
	56-60	368, 430	3-1285
MERCURY (See Comet)	62-63	All 6 & 8 Cyl. (Ex. Meteor)	3-1285
	62-63	All 6 & 8 Cyl. Meteor	3-1286
	59-61	All 6 & 8 Cyl.	3-1285
	56-58	All 6 & 8 Cyl.	3-1285
NASH	1956	6 Cyl. Ambassador w/Std. Trans. & H.M.	3-1287
PLYMOUTH	57-59	All 6 & 8 Cyl.	3-1288
	1956	All w/P.F.	3-1287
	51-55	All	3-1287
STUDEBAKER TRUCK	58-60	All 6 Cyl.	3-1288
THUNDERBIRD	56-63	All	3-1285
	59-60	430" Eng.	3-1285
WILLYS	55-60	6 Volt L6-226	3-1287