

S.V. 200, 202, 204, 210, 213, 261 (264)

C.V.

D.V.

CG 18 CODE GT-751-D PKG.

→ DEC 30 80 38331

EST. WGT. 2781 LBS.

STD. HRS. TIME 3 P M

DEC 31 1980

PROCESSES		APPROVED BY
() GT-751-D P		AJC 05-09-77
() GT-829-D A		MTW 05-16-77
() ()		DCG 05-18-77
() ()		
TYPED BY		
emw051977		

~~Check availability of N-8101~~

OK TO USE N-8104

EQUIPMENT		NAME:	USE LBS.	N CODE	ACCT LBS.
SV	2	MONASTRAL® GREEN G			
	1	Run 2-3" (±200 G) water into V-			
	2	Use station # , preset water meter per chart for water addition to full totes. Use mode 3 for N-8101-A, when 8104-A used instead use mode 4, & pump in ±200# 100% to the nearest tote ±2800#		8101-A	
		Gals of Water			
		Sequencer Steps			
		LOT 6 11 16 #100% %			
		933B 60 25 100 545.0 21.8 2500			
		932A 50 25 100 849.0 31.1 2730			
		936B 50 25 100 652.0 24.9			
		934A 50 25 100 783.0 29.0 2700			
		2829 #100% Total		8101-A	2829
	3	After last tote pumped, run in 100 gals of water & pump to clean system			
	4	Start agitator & stir 5 min			
	5	Record: pH 7.3 (6.5-7.5)			
	6	If above pH 7.5, adj to pH 6.0-7.5			
		NOTE: Add N-30-D 1 to 2# at a time using the minimum total amount of N-30-D			
		Record: pH M %		30-D	
	7	Flood to 82 "			
	8	Stop agitator			
Misc	9	Calc: Est Wgt			
	10	2829 #100% N-8101-A &/or N-8104-A x 0.986 = # Est			
		Record on make & process cards			
		SV 200 202 204 210 213 261 264			
		S 7 54" 62" 62" 53" 37" 42" 82"			
		Gal 3650 3670 3646 3684 3667 3654 3624			
		START 4:45PM FIN 8:00PM OPTR 211			