

possible, strongly supported, and with the dead ends capped to permit inspection and cleaning. All branch pipes should join the main at an angle of not greater than 45 deg, the junction being at the side or top of the larger end of a transformation piece. Branch pipes should not join the main pipes at points where the material from one branch would tend to enter the branch on the opposite side of the main.

Cleanout openings having suitable covers should be placed in the main and branch pipes so that every part of the system can be easily reached in case the system clogs. Either a large cleanout door should be placed in the main suction pipe near the fan inlet, or a detachable section of pipe, held in place by lug bands, may be provided.

Elbows and hoods should be made at least two gages heavier than straight pipe of the same diameter, in order to enable them to withstand the additional wear caused by changing the direction of flow. Elbows should preferably have a throat radius of at least one and one-half times the diameter of the pipe.

Every pipe should be kept open and unobstructed throughout its entire length, and no fixed screen should be placed in it, although the use of a trap at the junction of the hood and branch pipe is permissible, provided it is not allowed to fill up completely. The passing of pipes through firewalls should be avoided wherever possible, and floor sweep connections should be so arranged that foreign material cannot be easily introduced into them.

At the point of entrance of a branch pipe with the main duct, there should be an increase in the latter equal to their sum. Some state codes specify that the combined area be increased by 25 per cent. While this is not always good practice and is frequently done at the expense of a reduced air velocity, it is often done where future expansion of the exhaust system is contemplated.

Duct Resistance

The resistance to flow in any galvanized duct riveted and soldered at the joints may be obtained from Fig. 2, Chapter 32. The pressure drop through elbows depends upon the radius of the bend. For elbows whose centerline radii vary from 50 to 300 per cent of pipe diameter, the loss may be estimated from Table 6. It is sometimes convenient to express the resistance of an elbow in terms of an equivalent length of duct of the same diameter. Thus with a throat radius equal to the pipe diameter the resistance is equivalent to a section of straight pipe approximately 10 diameters long, while with a throat diameter radius $1\frac{1}{2}$ times the dia-

TABLE 6. LOSS THROUGH 90-DEG ELBOWS

ELBOW CENTER LINE RADIUS IN PER CENT OF PIPE DIAMETER	LOSS IN PER CENT OF VELOCITY HEAD
50	75
100	26
150	17
200 to 300	14

meter, the resistance is apparently the same as that of seven diameters of straight pipe.

COLLECTORS

The most common method of separating the dust and other materials from the air is to pass the mixture through a centrifugal or *cyclone* collector. In this type of collector the mixture of the air and material is introduced on a tangent, near the cylindrical top of the collector, and the whirling motion sets up a centrifugal action causing the comparatively heavy materials suspended in the air to be thrown against the side of the separator, from which position they spiral down to the tail piece, while the air escapes through the stack at the center of the collector.

The diameter of the cyclone should be at least 3.5 times the diameter of the fan discharge duct. When two or more separate ducts enter a cyclone, gates should be provided to prevent any back draft through a system which may not be operating. Cyclones working in conjunction with two or more fans should be designed to operate efficiently at two-thirds capacity rating.

If a cyclone is used to collect light dusts such as buffing wheel dusts, feathers and lint, the exhaust vent should be large enough to permit an air velocity of 200 to 500 fpm. This will require a cyclone of larger dimensions than given for the foregoing general case.

When a high collection efficiency is desired, or the material is very fine, multi-cyclones may be used. These are merely small cyclones arranged in parallel which utilize the principle of high centrifugal velocity to attain separation. The capacities and characteristics of this type of separator should be obtained from the manufacturers.

Dust Filters

Filters are used when the material collected by an exhaust system is valuable or cannot be separated efficiently from the air with an ordinary cyclone. They are also employed when it is desirable to recirculate the air drawn from a room by the exhaust system, which otherwise might entail considerable loss in heat. Bag filters which are properly housed should be operated under suction. *Bag houses* used in the manufacture of zinc oxide and other chemical products are operated on the positive side of the fan.

Wool, cotton and asbestos cloths, and paper are commonly used as filtering mediums. When woolen cloths are employed, the filtering capacities vary from $\frac{1}{2}$ to 10 cfm per square foot of filtering surface, depending on the character of the material collected. The rates for cotton and asbestos cloths are lower. The type of filter cloth and the rates of filtration depend, of course, on the material to be collected and the fan capacity. The time increase of resistance varies with the amount of material permitted to build up on the surface of the filter and can be determined only by experiment. The limits of the increase may be regulated by adjustment of the shaking or cleaning mechanism. These limits may be regulated further according to the capacity of the fan and the effective performance of the hoods and the duct system.