

the finest work in the
city costs no more



any sofa & chair
modernized and
re-upholstered

from \$99 both pieces, complete

Free
Decorator
Catalogue



If you
PHONE TODAY!
11 a.m. to 6 p.m. ONLY
Please call 3-3211, or
ZE 1300 (toll free)

Main Office & Showroom
111 W. Manchester, between
Figueroa & Vermont, L.A.
Open Daily 9 a.m. to 6 p.m.
Mon. & Fri. 10 a.m. to 5 p.m.
Branch Sales Rooms
1104 W. 19th Blvd., Los Angeles
1116 E. Southern Ave., Los Angeles
1043 Commercial Blvd., Los Angeles
1011 W. Century Blvd., Inglewood
118 E. Pacific, Anaheim Beach
645 Pacific Coast Hwy., Newport Beach
2001 Main Street, Denver City

- ★ All work supervised by a Master Designer. No apprentices permitted to work unsupervised here.
- ★ Every job stripped to frame beam and completely rebuilt. All springs tightened or replaced.
- ★ All padding and other interior material equal to or better than original quality.
- ★ Your choice of nearly 5,000 cover materials, all bought mill-direct for maximum value to you.
- ★ Free pick-up and delivery. Bonded estimators. Convenient terms. Full 5-year guarantee. You must be satisfied.

★ STAR DUST
Decorators

"decorator to the stars"

for California Outdoor Living!

PATIO FLOORS & BARBECUES of
FLAGSTONE, CEMENT, BRICK
PATIO ROOFS of FIBERGLASS,
ALUMINUM, REDWOOD



COMPLETE
PATIO
SERVICE

Los Angeles Times
5-26-1957

Bench Saw

Continued from Page fortythree

head, allowing the saw blade to come up through the saw slot. Make or purchase the metal angle braces. Attach to the sides of the housing and secure to the bench with 1/4" wood screws. This arrangement makes it possible to lift the housing off if one should care to use the head for grinding or another machine job. There are many attachments that can be operated with this head as a driving unit.

The fence (see drawing) is of white pine. Cut and break the corners slightly, as shown. Make the catch from a piece of band iron and attach at the rear with 1/4" wood screws.

Make the clamp from soft sheet steel. Cut out with a hack saw and clamp in a vise and bend the lower edge over. Note how holes are drilled.

Locate and drill a 1/2-inch hole in the front end of the fence 1 1/4 inches deep. Then, using a 1/4-inch drill, drill the holes on in to a depth of 1 inch. Using a 1/4-inch wood bit, drill the hole in the underside of the fence to meet the 1/2-inch hole. Set the 1/2-inch 20-threaded bolt in and screw a nut on and fill the hole—over the nut—with plastic wood and sand off. Slip the spring in as shown. Place the clamp in position and screw on a wing nut. Then set the 1/4" wood screw in at the top, leaving about 1/4 inch out. The spring forces the clamp out so that the fence may be set in place on the table. Tighten in position with the wing nut.

The miter gauge is made from 1/4-inch birch plywood. Scribe the circles and saw out on the jig saw or with a coping saw and sand smooth. Drill the hole through the center to take a No. 12 nail for a rivet.

BULLOCKS
DOWNTOWN

Keeps your
STUCCO
home beautiful
years longer

Sherwin-Williams
KEM-KRETE
Exterior Paint
Gallon, **7.15**

39
lovely stay-fresh
colors. It's made
especially for the West

Brushes on rolls on
fast. Dries quickly
to a weather tough
surface. Gives long w

Ask Sherwin-Williams
Bullock's Downtown for
decorating and color in

Sherwin-Williams,
Clark Floor, Bullock's Broadway



Bullock's
Broadway, 1000
Elm 1911, Sherwin-Williams
through Saturday 10:00 a.m. to 6:00 p.m.; Monday, 12:00