

Gas-Fired Boilers

Information on gas-fired boilers will be found in Chapter 25.

Either snap action or throttling control is available for gas boiler operation. This is especially advantageous in straight steam systems because steam pressures can be maintained at desired points, while at the same time complete cut-off of gas is possible when the thermostat calls for it.

Warm Air Furnaces

There are two general classes of gas-fired warm air furnaces, the gravity furnace which depends upon the natural tendency of heated air to rise, providing the proper circulation of heated air into the room, and the mechanical circulation furnace by which the air to be heated is forced through or drawn through the furnace by means of a fan.

Warm air furnaces are variously constructed of cast iron, sheet metal and combinations of the two materials. If sheet metal is used, it must be of such a character that it will have the maximum resistance to the corrosive effect of the products of combustion. With some varieties of manufactured gases, this effect is quite pronounced. Warm air furnaces are obtainable in sizes from those sufficient to heat the largest residence down to sizes applicable to a single room. The practice of installing a number of separate furnaces to heat individual rooms is peculiar to mild climates, such as that of Southern California. Small furnaces, frequently controlled by electrical valves actuated by push-buttons in the room above, are often installed to heat rooms where heat may be desired for an hour or so each day. These furnaces are used also for heating groups of rooms in larger residences. In a system of this type each furnace should supply a group of rooms in which the heating requirements for each room in the group are similar as far as the period of heating and temperature to be maintained are concerned. Bedrooms, living rooms, and dining rooms often present excellent possibilities for this type of furnace.

The same fundamental principle of design that is followed in the construction of boilers, that is, breaking the hot gas up into fine streams so that all particles are brought as close as possible to the heating surface, is equally applicable to the design of warm air furnaces. The desirability of using an appliance designed for gas, when gas is to be the fuel, applies even more strongly to furnaces than to boilers.

Codes for proportioning warm air heating plants, such as that formulated by the *National Warm Air Heating and Air Conditioning Association* (see note p. 419), are equally applicable to gas furnaces and coal furnaces. Recirculation should always be practiced with gas-fired warm air furnaces. It not only aids in heating, but is essential to economy. Where fans are used in connection with warm air furnaces for residence heating, it is well to have the control of the fan and of the gas so coordinated that there will be sufficient delay between the turning on of the gas and the starting of the fan to prevent blasts of cold air being blown into the heated rooms. An additional thermostat in the air duct easily may be arranged to accomplish this.

Floor Furnaces

Warm air floor furnaces are well adapted for heating first floors, or

where heat is required in only one or two rooms. A number may be used to provide heat for the entire building where all rooms are on the ground floor, thus giving the heating system flexibility as any number of rooms may be heated without heating the others. With the usual type the register is installed in the floor, the heating element and gas piping being suspended below. Air is taken downward between the two sheets of the double casing and discharged upward over the heating surfaces and into the room. The appliance is controlled from the room to be heated by means of a control lever located near the edge of the register. The handle of the control is removable as a precaution against accidental turning on or off of the gas to the furnace.

Space heaters are generally used for auxiliary heating, but may be, and are in many cases, installed for furnishing heat to entire buildings. Space heaters are quite extensively used for house heating in milder climates such as exist in the South and Southwest. With the exception of wall heaters, they are portable, and can be easily removed and stored during the summer season. Although they should be connected with solid piping it is sometimes desirable to connect them with flexible gas tubing in which case a gas shut-off on the heater is not permitted, and only A.G.A. approved tubing should be used.

Space Heaters

Parlor furnaces or *circulators* are usually constructed to resemble a cabinet radio. They heat the room entirely by convection, *i.e.*, the cold air of the room is drawn in near the base and passes up inside the jacket around a drum or heating section, and out of the heater at or near the top. These heaters cause a continuous circulation of the air in the room during the time they are in operation. The burner or burners are located in the base at the bottom of an enclosed combustion chamber. The products of combustion pass up around baffles within the heating element or drum, and out the flue at the back near the top. They are well adapted not only for residence room heating but also for stores and offices.

Radiant heaters make admirable auxiliary heating appliances to be used during the occasional cool days at the beginning and end of the heating season when heat is desired in some particular room for an hour or two. The radiant heater gives off a considerable portion of its heat in the form of radiant energy emitted by an incandescent refractory that is heated by a Bunsen flame. They are made in numerous shapes and designs and in sizes ranging from two to fourteen or more radiants. Some have sheet-iron bodies finished in enamel or brass while others have cast-iron or brass frames with heavy fire clay bodies. An atmospheric burner is supported near the center of the base, usually by set screws at each end. Others have a group of small atmospheric burners supported on a manifold attached to the base. Most radiant heaters are supported on legs and are portable; however, there are also types which are encased in a jacket which fits into the wall with a grilled front, similar to the ordinary wall register. Others are encased in frames which fit into fireplaces.

Gas-fired steam and hot water radiators are popular types of room heating appliances. They provide a form of heating apparatus for intermittently heated spaces such as stores, small churches and some types of offices and apartments. They are made in a large variety of shapes and sizes and are