

PLAINTIFF'S
EXHIBIT

WV-06169





PLAINTIFF'S
EXHIBIT

1976

MSI 771

FMSI

FRICION MATERIALS STANDARDS INSTITUTE



1977

BRAKE LINING & CLUTCH FACING AUTOMOTIVE DATA BOOK

All rights to the contents of this catalog are reserved by the Friction Materials Standards Institute, Inc. and the FMSI numbers and numbering systems used are protected by copyright.

The printing or reproduction of this catalog in whole or in part without written permission of the Friction Materials Standards Institute, Inc., E. 210 Route #4, Paramus, N. J. 07652, is prohibited.

Copyright © 1977 by Friction Materials Standards Institute, Inc.
Printed in U.S.A.

Form No. 8-6018

RECOMMENDED PROCEDURES FOR REDUCING ASBESTOS DUST DURING BRAKE SERVICING

Because studies have indicated that exposure to excessive amounts of asbestos dust may be a serious health hazard, OSHA has set maximum limits or levels of airborne asbestos dust to which workers may be exposed. Since most automotive friction materials normally contain a small amount of asbestos, it is important that people who handle brake linings and drum linings understand the nature of the problem and know the precautions to be taken.

Areas where brake work is done should be set aside, if possible, and entrances should be posted with an asbestos exposure sign as follows:

**Asbestos
Dust Hazard**
Avoid Breathing Dust
Wear Assigned Protective Equipment
Do Not Remain in Area Unless Your Work
Requires It
Breathing Asbestos Dust May Be Hazardous
To Your Health

The amount of asbestos in the dust from brake lining wear is normally at an extremely low level because of chemical breakdown during use, and if machining of friction material does not take place. Simple procedures will minimize exposure. During brake servicing, the mechanic should wear an air purifying respirator, either a throwaway or one with replaceable particulate filter(s), as approved by the Mining Enforcement and Safety Administration or MSHA. It should be worn during all procedures starting with the removal of the wheels and including reassembly.

3. During disassembly, all parts should be carefully placed on the floor to minimize the possibility of creating airborne dust. Dust should first be cleaned from the brake drums, brake backing plates and brake assemblies using an industrial type vacuum cleaner equipped with a high efficiency filter system. After vacuum cleaning, any remaining dust should be removed by using a rag soaked in water and wrung until nearly dry. Under no circumstances should compressed air or dry brushing be used for cleaning.
4. Of extreme importance are the precautions which must be taken during machining of friction material. This is the operation in brake servicing when exposure to asbestos dust is at its highest. In addition to the approved respirator, there must

be good exhaust ventilation and the work area should be maintained at least below the 1975 OSHA asbestos standards. There is one exception as to the amount of asbestos dust removal by the machine. The manual operator should be protected.

5. Industrial vacuum cleaner bags containing asbestos dust and linings used for wiping brake assemblies should be sealed in plastic bags and labeled with the following warning: Breathing asbestos dust may cause serious bodily harm.

Caution
Contains Asbestos Fibers
Avoid Creating Dust
Breathing Asbestos Dust May Cause Serious
Bodily Harm

All asbestos waste should be disposed of in accordance with the OSHA asbestos regulation. During removal of vacuum bags, an approved respirator, as described in (2) above should be worn.

6. All floor cleaning in areas where brakes are repaired should be done with the high efficiency industrial vacuum cleaner as described in (3) above. Under no circumstances should dry sweeping take place. Grinding (farding) machines should also be cleaned with such a vacuum cleaner and any remaining dust wiped with a damp cloth. An approved respirator as described previously should be used during this cleaning.
7. Although adherence to the above procedures should minimize any contamination of work clothing, it is necessary that the appropriate sections of the OSHA regulations on asbestos be followed when ceiling levels on asbestos dust exceed current standards. This could involve special clothing, change rooms, etc. At the very least the work clothes should not be taken home but should remain at work for industrial laundering.
8. Proper hygiene practices will help minimize exposure to asbestos dust. Wash thoroughly before eating and do not eat in the work area. Remember, smoking is harmful to the health and smoking coupled with breathing asbestos dust is extremely dangerous.

CAUTION: DO NOT BREATHE ASBESTOS DUST