

Dr. William J. Nicholson of the Mount Sinai School of Medicine (Ex. 84-74) cited data from Knight and Hickish (1970) that indicated that the concentration of asbestos ranged from 0.84 to 5.35 f/cc over a 60-minute sampling period when compressed air was being used to blow out the asbestos-containing residue from the brake drum. In the same study, a peak concentration of 87 f/cc was measured for a few seconds during brake cleaning performed with compressed air. Rohl et al. (1976) (Ex. 90-148) measured area concentrations (of unspecified duration) within 3-5 feet of operations involving the cleaning of brakes with compressed air and obtained readings ranging from 6.6 to 29.8 f/cc. Because of the high exposure levels that result from cleaning brake and clutch parts using compressed air, OSHA has prohibited this practice in the revised standard.

Ineffective Methods

When dry brushing was used to remove the asbestos-containing residue from the brake drums and wheel assemblies, peak exposures measured by NIOSH ranged from 0.81 to 0.81 f/cc, while 8-hour TWA levels were at the new standard's permissible exposure limit (PEL) of 0.2 f/cc (Ex. 84-283). Rohl and his colleagues (Ex. 90-148) collected area samples 1-3 feet from a brake cleaning operation being performed with a dry brush, and measured concentrations ranging from 1.3 to 3.8 f/cc; however, sampling times and TWA concentrations were not presented in the Rohl et al. study.

When a brush wetted with water, gasoline, or Stoddart solvent was used to clean the asbestos-containing residue from the affected parts, exposure levels (8-hour TWAs) measured by NIOSH also exceeded the new 0.2 f/cc PEL, and peak exposures ranged as high as 2.62 f/cc (Ex. 84-283).

Preferred Methods

Use of an engineering control system involving a cylinder that completely encloses the brake shoe assembly and a High Efficiency Particulate Air (HEPA) filter-equipped vacuum produced 8-hour TWA employee exposures of 0.01 f/cc and peak exposures ranging from nondetectable to 0.07 f/cc (Ex. 84-283). (Because this system achieved exposure levels below the standard's action level, it is described in detail below.) Data collected by the Mount Sinai Medical Center (Ex. 90-148) for Nilfisk of America, Inc., the manufacturer of the brake assembly enclosure system, showed that for two of three operations sampled, the exposure of mechanics to airborne asbestos fibers was nondetectable. For the third operator sampled by Mt. Sinai researchers, the exposure was 0.5 f/cc, which the authors attributed to asbestos that had contaminated the operator's clothing in the course of previous brake repair operations performed without the enclosed cylinder/vacuum system.

Some automotive repair facilities use a compressed-air hose to apply a solvent mist to remove the asbestos-containing residue from the brake drums before repair. The NIOSH data (Ex. 84-283) indicated that mechanics employing this method experienced exposures (8-hour TWAs) of 0.8

f/cc, with peaks of 0.25 to 0.68 f/cc. This technique, and a variant of it that OSHA believes is both less costly and more effective in reducing employee exposures, is described in greater detail above in Sections A and B.

D. Summary

In conclusion, OSHA believes that it is likely that employers in the brake and clutch repair industry will be able to avail themselves of the action level trigger built into the revised standard if they conscientiously employ one of the three control methods described above: the enclosed cylinder/HEPA vacuum system, the compressed air/solvent method, or the spray can/solvent mist system.

Appendix G to § 1910.1001—Substance Technical Information for Asbestos—Non-Mandatory

I. Substance Identification

A. Substance: "Asbestos" is the name of a class of magnesium-silicate minerals that occur in fibrous form. Minerals that are included in this group are chrysotile, crocidolite, amosite, tremolite asbestos, anthophyllite asbestos, and actinolite asbestos.

B. Asbestos, tremolite, anthophyllite, and actinolite are used in the manufacture of heat-resistant clothing, automotive brake and clutch linings, and a variety of building materials including floor tiles, roofing felts, ceiling tiles, asbestos-cement pipe and sheet, and fire-resistant drywall. Asbestos is also present in pipe and boiler insulation materials, and in sprayed-on materials located on beams, in crawlspaces, and between walls.

C. The potential for a product containing asbestos, tremolite, anthophyllite, and actinolite to release breathable fibers depends on its degree of friability. Friable means that the material can be crumbled with hand pressure and is therefore likely to emit fibers. The fibrous or fluffy sprayed-on materials used for fireproofing, insulation, or sound proofing are considered to be friable, and they readily release airborne fibers if disturbed. Materials such as vinyl-asbestos floor tile or roofing felts are considered nonfriable and generally do not emit airborne fibers unless subjected to sanding or sawing operations. Asbestos-cement pipe or sheet can emit airborne fibers if the materials are cut or sawed, or if they are broken during demolition operations.

D. Permissible exposure: Exposure to airborne asbestos, tremolite, anthophyllite, and actinolite fibers may not exceed 0.2 fibers per cubic centimeter of air (0.2 f/cc) averaged over the 8-hour workday.

II. Health Hazard Data

A. Asbestos, tremolite, anthophyllite, and actinolite can cause disabling respiratory disease and various types of cancers if the fibers are inhaled. Inhaling or ingesting fibers from contaminated clothing or skin can also result in these diseases. The symptoms of these diseases generally do not appear for 20 or more years after initial exposure.

B. Exposure to asbestos, tremolite, anthophyllite, and actinolite has been shown

to cause lung cancer, mesothelioma, and cancer of the stomach and colon. Mesothelioma is a rare cancer of the thin membrane lining of the chest and abdomen. Symptoms of mesothelioma include shortness of breath, pain in the walls of the chest, and/or abdominal pain.

III. Respirators and Protective Clothing

A. Respirators: You are required to wear a respirator when performing tasks that result in asbestos, tremolite, anthophyllite, and actinolite exposure that exceeds the permissible exposure limit (PEL) of 0.2 f/cc. These conditions can occur while your employer is in the process of installing engineering controls to reduce asbestos, tremolite, anthophyllite, and actinolite exposure, or where engineering controls are not feasible to reduce asbestos, tremolite, anthophyllite, and actinolite exposure. Air-purifying respirators equipped with a high-efficiency particulate air (HEPA) filter can be used where airborne asbestos, tremolite, anthophyllite, and actinolite fiber concentrations do not exceed 2 f/cc; otherwise, air-supplied, positive-pressure, full facepiece respirators must be used. Disposable respirators or dust masks are not permitted to be used for asbestos, tremolite, anthophyllite, and actinolite work. For effective protection, respirators must fit your face and head snugly. Your employer is required to conduct fit tests when you are first assigned a respirator and every 6 months thereafter. Respirators should not be loosened or removed in work situations where their use is required.

B. Protective Clothing: You are required to wear protective clothing in work areas where asbestos, tremolite, anthophyllite, and actinolite fiber concentrations exceed the permissible exposure limit (PEL) of 0.2 f/cc to prevent contamination of the skin. Where protective clothing is required, your employer must provide you with clean garments. Unless you are working on a large asbestos, tremolite, anthophyllite, and actinolite removal or demolition project, your employer must also provide a change room and separate lockers for your street clothes and contaminated work clothes. If you are working on a large asbestos, tremolite, anthophyllite, and actinolite removal or demolition project, and where it is feasible to do so, your employer must provide a clean room, shower, and decontamination room contiguous to the work area. When leaving the work area, you must remove contaminated clothing before proceeding to the shower. If the shower is not adjacent to the work area, you must vacuum your clothing before proceeding to the change room and shower. To prevent inhaling fibers in contaminated change rooms and showers, leave your respirator on until you leave the shower and enter the clean change room.

IV. Disposal Procedures and Cleanup

A. Wastes that are generated by processes where asbestos, tremolite, anthophyllite, and actinolite is present include:

1. Empty asbestos, tremolite, anthophyllite, and actinolite shipping containers;
2. Process wastes such as cuttings, trimmings, or reject material.