

utilized to induce a current of air to flow through a duct or casing, and this air current distributes the spray. *Fan propulsion* obviously consists of the utilization of fans to entrain and distribute the spray.

Industrial type direct humidifiers are commonly classified as (1) atomizing, (2) high-duty, (3) spray and (4) self-contained or centrifugal.

Atomizing Humidifiers

There are several types of atomizing humidifiers, all of which rely upon compressed air as the atomizing and distributing agency, similar to the familiar method used in ordinary nasal atomizers. Compressed air (ordinarily about 30 lb per square inch) is supplied from a centrally-located air compressor through pipe lines to the atomizing units. The air lines are usually horizontal and parallel to water lines which supply water by gravity from a float tank. The water in the tank is maintained at a constant level slightly lower than the outlets of the atomizers themselves and is drawn constantly to the atomizer by aspiration when compressed air is supplied. This aspiration ceases and the flow of water stops when the air supply is cut off. The water should not be supplied under pressure to atomizers because of the possibility of leakage, drip, or coarse spray which cannot be permitted when water is supplied by aspiration.

High-Duty Humidifiers

Water is supplied to high-duty humidifiers under high pressure (usually about 150 lb per square inch) through pipe lines from a centrally-located pumping unit. The spray-generating nozzle which is of the impact type is located in a cylindrical casing. A drainage pan provides for the collection and return of unevaporated water which flows through a return pipe to a filter tank, from which it is recirculated. A powerful air current is forced through the humidifier by means of a fan mounted above the unit.

The air enters from above, is drawn through the head, charged with moisture, and cooled to the wet-bulb temperature. It then escapes from the opening below at a high velocity in a complete and nearly horizontal circle. The spray is evaporated and the resulting vapor diffused. This distribution of fine spray over the maximum possible area promotes complete and rapid vaporization even at high humidities.

Spray Humidifiers

This type of humidifier consists of an impact spray nozzle in a cylindrical casing with a drainage pan below it. The aspirating effect of the spray nozzle induces a moderate air current through the casing which distributes the entrained spray. The general method of circulating and returning the water is similar to that employed for high-duty humidifiers. A suitable pump and centrally-located filter tank are required.

Self-Contained Humidifiers

The self-contained or centrifugal humidifier has the ability to generate and distribute spray without the use of air compressors, pumps, or other auxiliaries. These may be used either singly or in groups. In large installations, where suitable connections are provided to permit the cleaning and servicing of individual units without affecting the room as a whole, group control of the water and power may be employed.

AIR DEHUMIDIFICATION WITH WASHERS

Moisture removal from an air-vapor mixture can be accomplished by use of an air washer so long as the temperature of the spray medium is lower than the dew-point of the air passing through the unit. The final dry-bulb temperature and the relative humidity of the air leaving a dehumidifier washer are dependent upon: the air velocity, the length of air travel through the sprays, the dry- and wet-bulb temperatures of the entering air, the spray temperature, the number of spray banks and nozzles, the quantity of spray medium handled, and the effectiveness of the nozzles in breaking the spray into a fine mist.

Both sensible and latent heat are removed in the process of dehumidification by cooling. Abstraction of sensible heat occurs during the entire time that the air is in contact with the spray medium. Latent heat removal takes place as condensation occurs. Therefore, the lower the spray temperature the greater the amount of moisture removal per pound of dry air, all other conditions remaining the same. Washers with two or more banks of sprays are usually selected for comfort air conditioning installations. Such washers will cool the air to within 1 or 2 F of the leaving spray water temperature.

Where a limited supply of cold water is available multiple stage washers may be used to an advantage. The cool water is pumped through the multiple spray systems in series. By this arrangement the entering air is cooled first by the warmer water and finally by the cooler water which gives the maximum amount of cooling with the minimum amount of water. The approximate temperatures of water from wells at depths of 30 to 60 ft are given in Fig 4¹. Frequently the temperature of the city water main supply is low enough during the summer to permit an appreciable cooling effect. Table 1 lists the maximum city water main temperatures for various localities in the United States and Canada.

Air washers using refrigerated spray generally have their own recirculating pumps. These pumps deliver to the sprays a mixture of water from the washer sump, which has not been re-cooled, and refrigerated water. The quantities of each are controlled by a three-way or mixing valve actuated by a dew-point thermostat located in the washer air outlet.

ATMOSPHERIC WATER COOLING EQUIPMENT

In the operation of a refrigerating plant or a condensing turbine, one of the main problems is the removal and dissipation of heat from the compressed refrigerant or the discharged steam. This is accomplished ordinarily by first transferring the heat of the gas to water in a heat exchanger, from which water it may then be dissipated in a number of ways. If the plant is situated on the banks of a river or lake, an intake may be taken up-stream or at a considerable distance from the discharge, to prevent mixing of the heated discharged water with the inlet water. If the source of cooling water is a city supply or a well, the discharge water may be run into the nearest sewer or open waterway. Lacking an unlimited water supply, or in cases where city water is too expensive

¹Temperature of Water Available for Industrial Use in the United States, by W. D. Collins (U. S. Geological Survey, Water Supply Paper No. 520 F).