

ASBESTOS HANDLING AND DISPOSAL

Page 7 of 10

July 25, 1985

NOTES AND REFERENCES

4. The Area Mechanical Foreman following the job should prepare a purchase requisition and shipping notice (SR-630). The requisition must include DuPont ID X05.
 5. Until the material is picked up by the vendor, it must be stored in a place where the bags will not be punctured or otherwise damaged.
- o The Shipping notice must bear the following: SRW Code-13 Description - Use Material, Primarily insulation containing asbestos.
Class I
TDWR Code - 170750
Disposition - Off-Site

When the material is shipped, the responsible Mechanical Foreman must fill out the Part I section of a TDWR Industrial Waste Shipping Control Ticket form, which the carrier truck driver will bring with him for each shipment or truck load.

F. HYGIENE

1. Separate lockers for work clothes and street clothes must be provided to prevent contamination for known exposure to high level concentrations.
2. Special clothing (coveralls) should also be provided for high concentrations such as spraying and demolition of asbestos insulation.

DUP 0908713