

S.V. 200, 202, 204, 210, 213, 261, 264 C.V.

CG 20 CODE BT-297-D PKG.

→ AUG 27 80 36925
EST. WGT. 2101 LBS.

PUNCHED & CHECKED

STD. HRS. TIME 7A SEP - 2 1987

D.V.

PROCESSES		APPROVED BY
() BT-297-D	M)	AJC 3-11-77
()	()	DCG 3/11/77
()	()	MTW 3/15/77
()	()	
TYPED BY		
NE 3/19/77		

OK-KLS

NON-BLEEDING

QUIPMENT	NAME:	USE LBS.	N CODE	ACCT. LBS.
SV 1	MONASTRAL® BLUE G			
	Run 2-3" (±200-G) water into V-210			
	Use station # 3, Preset water meter per chart for water addition to full totes then using Mode 3, pump in (± 2100# 100%)		8600-A	
	GALS OF WATER			
	SEQUENCER STEPS			
	LOT 6 11 16 #100% %			
	353-A 25 20 50 310 12.4 2500		8600-A	2124
	353-A 25 20 50 303 14.6 2500			
	355-A 25 20 50 308 12.0 2500			
	357-A 25 20 50 365 14.6 2500			
	354-A 25 20 50 253 10.1 2500			
	354-A 25 20 50 233 10.2 2500			
	356 25 20 50 268 11.9 2254			
	Total 2124 #100%			
	Turn on agitator			
	Flood to 53"			
	Stop Agitator			
Misc. 2	Calculate Est Wgt: 2124 #100% N-8600-A x 0.989 = 2101 " Est Wgt.			
	Note: Record Est. Wgt. on Make & Process Cars.			
	S.V 200 202 204 210 213 261 264			
	S-4 54" 62" 62" 53" 37" 42" 82"			
	GALS 3650 3670 3646 3684 3667 3654 3624			
	START 3:00 PM FIN 9:10 PM QPTR 166			