

S.Y. 200, 202, 204, 210, 213, 261, 264

C.V.

D.Y.

CG 18 CODE GT-674-D PKG.

→ MAY -0.81-31513
EST. WGT. ~~2300~~ LBS.

EST. WGT. 2300 LBS.

STD. HRS.	TIME	M
1	10:00	10
2	10:15	10
3	10:30	10
4	10:45	10
5	11:00	10
6	11:15	10
7	11:30	10
8	11:45	10
9	12:00	10
10	12:15	10
11	12:30	10
12	12:45	10
13	13:00	10
14	13:15	10
15	13:30	10
16	13:45	10
17	14:00	10
18	14:15	10
19	14:30	10
20	14:45	10
21	15:00	10
22	15:15	10
23	15:30	10
24	15:45	10
25	16:00	10
26	16:15	10
27	16:30	10
28	16:45	10
29	17:00	10
30	17:15	10
31	17:30	10
32	17:45	10
33	18:00	10
34	18:15	10
35	18:30	10
36	18:45	10
37	19:00	10
38	19:15	10
39	19:30	10
40	19:45	10
41	20:00	10
42	20:15	10
43	20:30	10
44	20:45	10
45	21:00	10
46	21:15	10
47	21:30	10
48	21:45	10
49	22:00	10
50	22:15	10
51	22:30	10
52	22:45	10
53	23:00	10
54	23:15	10
55	23:30	10
56	23:45	10
57	00:00	10
58	00:15	10
59	00:30	10
60	00:45	10
61	01:00	10
62	01:15	10
63	01:30	10
64	01:45	10
65	02:00	10
66	02:15	10
67	02:30	10
68	02:45	10
69	03:00	10
70	03:15	10
71	03:30	10
72	03:45	10
73	04:00	10
74	04:15	10
75	04:30	10
76	04:45	10
77	05:00	10
78	05:15	10
79	05:30	10
80	05:45	10
81	06:00	10
82	06:15	10
83	06:30	10
84	06:45	10
85	07:00	10
86	07:15	10
87	07:30	10
88	07:45	10
89	08:00	10
90	08:15	10
91	08:30	10
92	08:45	10
93	09:00	10
94	09:15	10
95	09:30	10
96	09:45	10
97	10:00	10
98	10:15	10
99	10:30	10
100	10:45	10

PROCESSES

() GT-674-D	(Y)	AJC 1-16-78
() GT-680-P	(K)	DCG 1-18-78
(A) GC-3-A	()	MTW 1-24-78
()	()	
TYPED BY		
NSA 3-22-78		

() GT-674-D	(Y)	AJC 1-16-78
() GT-680-P	(K)	DCG 1-18-78
(A) GC-3-A	()	MTW 1-24-78
()	()	
TYPED BY		
NSA 3-22-78		

() GT-674-D	(Y)	AJC 1-16-78
() GT-680-P	(K)	DCG 1-18-78
(A) GC-3-A	()	MTW 1-24-78
()	()	
TYPED BY		
NSA 3-22-78		

NON-BLEEDING

EQUIPMENT		NAME: MONASTRAL® GREEN B	USE LBS.	N CODE	ACCT. LBS.
SV	1	Run 2-3" (#200G) water into V-			
1	2	Use station # _____, preset water meter per chart for water addition to full totes. Use Mode 3 for N-8101-A full totes & mode 2 for stumping totes. When 8104-A scheduled, use mode 4 for pumping full totes & mode 1 for stumping tote. Pump in thru 20-mesh screen		8101-A	2748
<i>USE N-8101A</i>					
<i>WT</i>					
Gals of Water Sequencer Steps					
	LOT	6	11	16	#100%
98SB	534	73-A	100	20	75
73A	545	73-A	100	20	75
73B	543	102-A	"	"	576
100A	550	100-A	"	"	550
108B	576	985-A	"	"	534
#100% Total					
Turn on agitator, use station # _____ & pump in					
	LOT		#100%	%	
	512		45	25%	176
After last tote pumped run in 100 gal water & pump to SV to clean line					
314	5	Run 18" (140 G) water into V-314 & heat to 80-100°F	75		75
2	6	Turn on agitator & add in 2-3 min	105	530-A	105
	7	Stir 5 min & Record: pH 7.7 (10.0-10.5)			
	8	Stir 15 min or longer to dissolve for S 13			
304	9	Run 8" (98 G) water into V-304 & start agitator	25		25
3	10	Add in ± 1 min & stir to dissolve for S 14	40	20-A	40
SV	11	After 5 min or longer stir Record: pH 8.7 (8.0 or above)			
4	12	If necessary adj to pH 8.0 or above Assume 50% & Record: pH		7-D	
	13	Run in V-314 thru 20 mesh screen & stir 10 min			
	14	Run in V-304 in 1-3 min & stir 5 min			
	15	Record: pH 8.5 (10.5-11.5)			
	16	Flood to 82" & stop agitator			
S	16	200	202	204	210
IN.		54	62	62	53
GAL.		3650	3670	3646	3684
					3667
					3654
					3624
START		FIN		OPTR	
7:00 AM		1:45 PM		3:20	