

COMBUSTION OF GAS

The majority of gas burners utilized in central domestic heating plants are of the Bunsen type and operate with a non-luminous flame. In this

TABLE 9. REPRESENTATIVE PROPERTIES OF GASEOUS FUELS,
BASED ON GAS AT 60 F AND 30 IN. HG.

Gas	BTU PER CU FT		SPECIFIC GRAVITY, AIR = 1.00	AIR REQUIRED FOR COMBUSTION, (Cu Ft)	PRODUCTS OF COMBUSTION				THEORETICAL FLAME TEMPERATURE, (DEG F)
	High (Gross)	Low (Net)			Cubic Feet			ULTIMATE CO ₂ Dry Basis	
					CO ₂	H ₂ O	Total with N ₂		
Natural gas—California	1200	1087	0.67	11.26	1.24	2.24	12.4	12.2	3610
Natural gas—Mid-Continental	967	873	0.57	9.17	0.97	1.92	10.2	11.7	3580
Natural gas—Ohio	1130	1025	0.65	10.70	1.17	2.16	11.8	12.1	3600
Natural gas—Pennsylvania	1232	1120	0.71	11.70	1.30	2.29	12.9	12.3	3620
Retort coal gas	575	510	0.42	5.00	0.50	1.21	5.7	11.2	3665
Coke oven gas	588	521	0.42	5.19	0.51	1.25	5.9	11.0	3660
Carbureted water gas	536	496	0.65	4.37	0.74	0.75	5.0	17.2	3815
Blue water gas	308	281	0.53	2.26	0.46	0.51	2.8	22.3	3800
Anthracite producer gas	134	124	0.85	1.05	0.33	0.19	1.9	19.0	3000
Bituminous producer gas	150	140	0.86	1.24	0.35	0.19	2.0	19.0	3160
Oil gas	575	510	0.35	4.91	0.47	1.21	5.6	10.7	3725

type of burner part of the air required for combustion is mixed with the gas as primary air, the air and gas mixture being fed to the burner ports. Additional secondary air is introduced around the flame by draft inspiration. In the luminous flame burner, which is sometimes used, all of the air for combustion is brought in contact with the flame as secondary air. This secondary air should be brought into intimate contact with the gas.

Some makes of burners use radiants or refractories to convert some of the energy in the gas to radiant heat. The radiants also serve as baffles in directing the flow of the products of combustion.

The quantity of air given in Table 9 is that required for theoretical combustion, but with a properly designed and installed burner the excess air can be kept low. In order to insure freedom from carbon monoxide under conditions which may obtain in installations, it is customary to design gas burning appliances for a supply of 30 to 35 per cent of excess air. In individual installations in which flue gas analyses are made, the

excess air is sometimes reduced to approximately 20 per cent. The division of the air into primary and secondary is a matter of burner design, the pressure of gas available, and the type of flame desired.

The air gas ratio has a decided effect upon flame propagation. It is necessary that the gas will flow out of the burner ports fast enough so that the flame cannot travel back into the burner head, i.e. *flash back*, but the velocity must not be so high that it blows the flame away from the port.

The maximum and minimum flow speeds from burner ports which may be permitted are known to be very close together when air-gas mixtures in theoretical proportions are being supplied to the burner. As the air-gas ratio is lowered, and the mixture becomes more *gas rich*, the limiting speeds become farther apart, until with 100 per cent gas, in an all-yellow flame, flash back cannot occur and a much higher velocity is needed to blow off the flames.

SOOT

The deposit of soot on the flue surfaces of a boiler or heater acts as an insulating layer over the surface and reduces the heat transmission to the water or air. The *Bureau of Mines Report of Investigations No. 3272*⁶ shows that the loss of seasonal efficiency is not so great as has been believed and usually is not over 6 per cent because the greater part of the heat is transmitted through the combustion chamber surfaces. The *Bureau of Standards Report BMS 54*⁷ points out that, although the decrease in efficiency of an oil fired boiler due to soot deposits is relatively small the attendant increase in stack temperature may be considerable.

The soot accumulation clogs the flues, reduces the draft, and may prevent proper combustion.

CONDENSATION AND CORROSION

Sulphur dioxide or trioxide formed by the combustion of fuels is the corroding element in flue gases and becomes active whenever moisture is available for the formation of sulphurous or sulphuric acid. It is therefore necessary to maintain a flue gas temperature above 175 F in all parts of appliances, and consequently it is not practicable to recover the latent heat in flue gases. Since some unpreventable condensation occurs during the warming-up period, it is important to design appliances so that all surfaces reach quickly a temperature above the dew-point of the flue gases or have corrosion resistant properties enabling them to withstand the corrosive effect.

REFERENCES

- Fuels and Their Combustion, Haslam and Russell (McGraw-Hill Co., 1926).
Principles of Combustion in the Steam Boiler Furnace, Arthur D. Pratt (Babcock and Wilcox Co.).

⁶Effect of Soot on Heat Transmission in Boilers (*U. S. Bureau of Mines Report of Investigation No. 3272*).

⁷Effect of Soot on the Rating of an Oil-Fired Heating Boiler (*National Bureau of Standards Report BMS 54*).