

- o Limit access to authorized personnel with proper protective clothing.
- o Wet down all insulation with water after removing any covering or vapor barrier (i.e., aluminum, tar, paper, etc).
- o Avoid sawing; knife cutting is preferred.
- o Remove all asbestos insulation from pipe or equipment.
- o Wipe off asbestos fiber remaining on exposed pipe with a wet cloth.
- o Place insulation and cloth in plastic bags and seal securely prior to disposal.
- o Thoroughly decontaminate dismantled insulated pipe by vacuuming with a HEPA-filter vacuum cleaner and by wiping with a wet cloth. Or wrap sections of the pipe in plastic sheeting and tape securely for disposal.