

DAY

Saturday

MORNING:

INBOUND & INNER PLANT WORK

EMPTY VCM CARS

Full empty vcm and replace with
load. Bill empties per attached
instructions

CARS TO WEIGH

CONX 45733 to scale lead

CARS TO SPOT

weigh PLCX 43239

Middle lead

weigh GATX 14172 ^{5E} Pt span

weigh PLCX 43710

Middle lead PLCX 43854

9

weigh PLCX 43741

Middle lead

weigh PLCX 43745

Middle lead

AFTERNOON:

OUTBOUND

LOADS TO GO

EMPTY

CONX 1934 - weigh - billing instruction
attached