

6LD31594

Handwritten notes and a downward arrow.

THE AMERICAN PAINT WORKS
DIVISION
THE GLIDDEN COMPANY
NEW ORLEANS, LOUISIANA *

EXTERIOR-INTERIOR
FLORENAMET
QUICK-DRYING
861 DECK GRAY

Climate

Fluorescent
White made
in kitchen
oven. Knead
in desired
color.
Be sure you
oroughly mix
thoroughly
FOR USE
cool 15% a
wash with a
brush the
surface the
from the c
FLOOR FL
necessary a
last coat a
two or three
Covers from

PAINTS

THIN

TIME TESTED

PAINTS • VARNISHES • LACQUERS • ENAMELS

FLORENAMEL

Florenamel is a new innovation in the line of floor coatings for interior or exterior use. While made especially for interior or porch floors, it is also an ideal finish for dadoes in kitchens and bathrooms. Florenamel is also adapted for finishing concrete floors, worn linoleum, woodwork, and furniture where a durable high gloss, washable surface is desired.

DIRECTIONS

Stir this enamel well before using.

Be sure surface is clean and dry. Remove all polishes, wax or grease by washing thoroughly with turpentine. When washing cement with zinc sulphate, allow to dry thoroughly before painting.

FOR USE ON INSIDE FLOORS, LINOLEUM AND FURNITURE—Reduce the first coat 10% with turpentine. Allow to dry overnight or 16 to 24 hours in cold damp weather, then apply second coat as it comes from the can.

FOR CEMENT SURFACES—First clean off all grease and dirt. If cement is new, wash with a solution of two pounds of zinc sulphate to a gallon of water—this will neutralize the alkali in the cement. Reduce the first coat of enamel with one quart of turpentine to the gallon of Florenamel. The second coat is to be applied as it comes from the can.

PORCH FLOORS AND STEPS—On surfaces previously painted a thorough cleaning is necessary and after complete drying, apply one or two coats if desirable of Florenamel allowing overnight drying at least between coats. On new or unpainted surfaces use Lastic-Seal as first or priming coat, follow with one or two coats of Florenamel. The first coat of Florenamel, if two are used, can be thinned 10% with Turpentine. Allow two or three days for Lastic-Seal to dry and overnight between coats of Florenamel. Covers from 500 to 600 square feet to the gallon depending on the surface.

53

GLD31595