

ASBESTOS HANDLING AND DISPOSAL

Page 4 of 10

July 25, 1985

NOTES AND REFERENCES

procedure is required. Monitoring results as outlined in Paragraph G is also required.

Small tubing that has been wrapped with asbestos tape or sleeve material must be sealed with a water-proof material such as Lagtone*.

9. Asbestos containing gaskets or gasket material must be stored in plastic sheathing and vacuumed to prevent accumulation of dusts. The gasket storage cabinets or drawers must be labeled clearly to identify the contents.

C. WORK PRACTICES

1. The minimum requirements for any job involving asbestos insulation are:

- a) Use of wet method.
- b) Use approved respirator.
- c) Proper waste disposal.
- d) Caution label if unbound asbestos is left overnight.

- o Where measurements on a previous job of the same or a similar nature demonstrated asbestos concentrations within allowable limits.
- o Ref. Paragraph E of this procedure.
- o Ref. Figure 2, of this procedure.

2. If the job involves more than two manhours or if unusual dusting is anticipated, the following precautions must be considered along with those listed in Paragraph C above.

- a) Monitoring
- b) Use of protective clothing.
- c) Barricades and posting of temporary warning signs.

- o Contract Process Lab, Monitoring Group.
- o Ref. Figure 1, of this procedure.