

APPLICATION CHART—(continued)

MAKE & YEARS		MODELS	TRANSMISSION MOUNT	QTY.
CORVAIR				
1965-66	All	(Ex Forward Control)	3-8712	2
1964-65	w/Forward Control		3-5191	2
1960-63	All	(L & R Front)	3-5191	2
CORVETTE				
1963-66	All		3-5192	1
1953-62	All	(Exc. 53-55 Std. Trans.)	3-5100	1
DODGE (Truck)				
1960	All Series 500, 600 W/Torqmatic	Upper	3-5056	1
		Lower	3-5058	1
1958-60	All Series 700 W/Torqmatic	Upper	3-5056	1
		Lower	3-5058	1
1958-59	All Series 500, 600 W/Torqmatic	Upper	3-5056	1
		Lower	3-5058	1
FORD (Passenger) (See Thunderbird)				
1957-59	All		3-5132	1
1954-56	All		3-5110	1
1951-53	All		3-5110	1
1949-50	All		3-5065	1
MERCURY				
1950-56	All	(Exc. 1950 Std. Trans.)	3-5110	1
THUNDERBIRD				
1957	All W/292, 312 Eng.		3-5132	1
1955-56	All		3-5110	1
VOLKSWAGEN				
1961-62	All	(Front)	3-5188	2
1960	All	(Front)	3-5189	2
1953-59	All	(Front)	3-5188	2
WILLYS				
1950-61	All 4 Cyl. Truck, Jeep	Upper	3-5020	1
		Lower	3-5021	1

* Not Available