

TRADE MARK

Climatic

THE

PAINTS

INTERIOR FINISH

GLOSS

4500 WHITE

THE AMERICAN PAINT WORKS

DIVISION

THE GLIDDEN COMPANY

* NEW ORLEANS, LOUISIANA *

Unexcelled
other phons
quantity will

Slr. Unwen.
ON PLAST
have partic
line after
solution (5
OLD PAINT
age and re
recommen
at thirties
to the
Allow this
On wood
NEW UNP
siding fire
to dry ever
Interior Bu
Finish Glen
Undercoat

GLD31603

Pyment 44.2%
Titanium 6.8%
Bari Carbonate 8.2%

TIME TESTED

PAINTS · VARNISHES · LACQUERS · ENAMELS

INTERIOR FINISH GLOSS

Unexcelled for the finishing of walls, ceilings, and woodwork of kitchen, bathrooms, and other places where a durable enamel, tile-like finish is desired. It can be washed frequently without impairing its brilliancy.

DIRECTIONS

Stir thoroughly with a lifting motion.

ON PLASTER SURFACES—Be sure surface is dry and free from dirt, grease and loose particles. All new plaster or cement walls that show indication of alkali or active lime after testing with Phenolphthalein should be given a wash coat of Zinc Sulphate solution (two pounds of Commercial Zinc Sulphate dissolved in one gallon water).

OLD PAINTED SURFACES—Walls. If old paint has become porous and worn with age and repeated washings, apply a coat of Interior Base Coat and then proceed as recommended for new unpainted surfaces. If old paint is in good condition, one coat of Interior Finish Gloss is often sufficient. If two coats are considered necessary, apply a first coat of Interior Finish Gloss mixed with equal parts of Interior Base Coat. Allow this to dry then apply a coat of Interior Finish Gloss as it comes from the can. On woodwork in place of Base Coat use Under-Name (Enamel Undercoat).

NEW UNPAINTED SURFACES—On unpainted walls make sure that all water resulting from washing has dried out. For first coat apply Interior Base Coat. Allow to dry overnight then apply a mixture of one-half Interior Finish Gloss and one-half Interior Base Coat. After this has dried 24 hours apply a finishing coat of Interior Finish Gloss as it comes from the can. On woodwork use Under-Name (Enamel Undercoater) in place of Base Coat.

80

GLD31604