

S.V. 200, 202, 204, 210, 213, 261, 264 C.V.

CG 18 CODE GT-751-D

PKG.

Dec-8-80 37996
EST. WGT. 2899 LBS.

1218

STD. HRS. _____ TIME _____ M

D.V.

PROCESSES		APPROVED BY
() GT-751-D	P)	AJC 05-09-77
() GT-829-D	(A)	MTW 05-16-77
()	()	DCG 05-18-77
()	()	
TYPED BY		
emw051977		

CLEAN UP LEAVE ONE STUMP ONLY

NON-BLEEDING

EQUIPMENT	NAME	USE LBS.	N CODE	ACC LBS
SV	MONASTRAL® GREEN G			
2	1 Run 2-3" (± 200 G) water into V- <u>264</u>			
	2 Use station # <u>2</u> , preset water meter per chart for water addition to full totes. Use mode 3 for N-8101-A, when 8104-A used instead use mode 4, & pump in 2000 # 100% to the nearest tote <u>2800#</u>		8101-A	<u>2940</u>
	Gals of Water			
	Sequencer Steps			
	LOT 6 11 16 #100% %			
	<u>924A</u> 100 20 75 801 29.4 2725			
	<u>923B</u> 100 20 75 577 26.4 2500			
	<u>922A</u> 100 20 75 676 27.0 2505			
	<u>924A</u> 100 20 75 886 32.7 2770			
	<u>2940#100% Total</u>		8101-A	
	13 After last tote pumped, run in 100 gals of water & pump to clean system			
	4 Start agitator & stir 5 min			
	5 Record: pH <u>7.8</u> (6.5-7.5)			
	6 If above pH 7.5, adj to pH 6.0-7.5			
	NOTE: Add N-30-D 1 to 2# at a time using the minimum total amount of N-30-D			
	Record: pH <u>7.4</u> M <u>12</u> . <u>80.91</u> %		30-D	<u>1</u>
	7 Flood to <u>82</u> "			
	8 Stop agitator			
Misc	9 Calc: Est Wgt			
2	<u>2940#100% N-8101-A &/or N-8104-A x 0.986 = 2899# Est</u>			
	10 Record on make & process cards			
	SV 200 202 204 210 213 261 264			
	S 7 54" 62" 62" 53" 37" 42" 82"			
	Gal 3650 3670 3646 3684 3667 3654 3624			
	START <u>7:30 Pm.</u> FIN <u>4:1 Pm.</u> OPTR <u>11/88</u>			

MAKING INSTRUCTIONS: BATCH UNIT

CG 18 CODE GT-751-D. PKG.

DEC 28 80 37989

EST. WGT. 2935 LBS.

STD. HRS. TIME M

D.V.

PROCESSES		APPROVED BY
()	GT-751-D (P)	AJC 05-09-77
()	GT-829-D (A)	MTW 05-16-77
()	()	DCG 05-18-77
()	()	
TYPED BY		
emw051977		

10-1132

NON-BLEEDING

EQUIPMENT	NAME	USE LBS.	N CODE	ACCT LBS.
SV	MONASTRAL® GREEN G			
2	Run 2-3" (±200 G) water into V-210			
	Use station # 3, preset water meter per chart for water addition to full totes. Use mode 3 for N-8101-A, when 8104-A used instead use mode 4, & pump in ±2000# 100% to the nearest tote ±2800		8101-A	2876
	Gals of Water Sequencer Steps			
	LOT 6 11 16 #100% %			
	916-B 40 15 100 922 33.4 2760			
	924-B 15 15 100 834 30.6 2725			
	923-A 35 15 100 543 21.7 2500			
	925-B 25 20 100 577 22.2 2600			
	2876 #100% Total		8101-A	
	After last tote pumped, run in 100 gals of water & pump to clean system			
	Start agitator & stir 5 min			
	Record: pH 8.5 (6.5-7.5)			
	If above pH 7.5, adj to pH 6.0-7.5			
	NOTE: Add N-30-D 1 to 2# at a time using the minimum total amount of N-30-D			
	Record: pH 7.1 M 12, 30.31 % 4 30-D 1			
	Flood to 53"			
	Stop agitator			
Misc	Calc. Est Wgt			
2	2876 #100% N-8101-A &/or N-8104-A x 0.986 = 2835# Est			
	Record on make & process cards			
	SV 200 202 204 210 213 261 264			
	57 54" 62" 62" 53" 37" 42" 82"			
	Gal 3650 3670 3646 3684 3667 3654 3624			
	START 3:PM 6:30P	FIN 6:30PM 7:30P	OPTR 88 438	