

March 26, 1975

TO: ALL EMPLOYEES

FROM: JIM WRIGHT

SANITIZING INSTRUCTIONS

Spray inside of respirator lightly with sanitizing fluid.
Gently absorb all excess fluid while cleaning the area
with absorbent tissue.

Enclosure 113

HER 0008832