

S.V. 200, 202, 204, 210, 213, 261, 264

C.V.

D.V.

CG 18 CODE GT-674-D PKG.

→ MAY -0-81-21352

EST. WGT. 2308 LBS.

STD. HRS. TIME M

PROCESSES		APPROVED BY	
() GT-674-D	(Y)	AJC	1-16-78
() GT-680-P	(K)	DCG	1-18-78
(A) GC-3-A	()	MTW	1-24-78
()	()		
TYPED BY		NSA 3-22-78	

DIA V.264

USE N-8101 LOT 87A, 748*

87B, 768*

88A, 674*(MAKE STUMP)

T-273 ✓

T-391

T-178 ✓

USE N-8600 ANY LOT

NON-BLEEDING

EQUIPMENT	NAME: MONASTRAL® GREEN B	USE LBS.	N CODE	ACCT. LBS.
SV 1	1 Run 2-3" (#200G) water into V-264			
	2 Use station # 2, preset water meter per chart for water addition to full totes. Use Mode 3 for N-8101-A full totes & mode 2 for stumping totes. When 8104-A scheduled, use mode 4 for pumping full totes & mode 1 for stumping tote. Pump in thru 20-mesh screen			2190
	Gals of Water		8101-A	
	Sequencer Steps			
	LOT 6 11 16 #100%			
	87A 50 25 50 748 29.9 2500			
	87B 50 768 30.7 2500			
	88A 674 30.6 2247			
	2190 #100% Total			
	3 Turn on agitator, use station # 8 pump in		8600-A	30
	LOT #100%			
	522B 30 11.9 252			
	4 After last tote pumped run in 100 gal water & pump to SV-264 to clean line			
314 2	5 Run 18" (140 G) water into V-314 & heat to 80-100°F			
	6 Turn on agitator & add in 2-3 min	125	530-A	125
	7 Stir 5 min & Record: pH 10.1 (10.0-10.5)			
	8 Stir 15 min or longer to dissolve for S 13			
304 3	9 Run 8" (98 G) water into V-304 & start agitator			
	10 Add in 1 min & stir to dissolve for S 14	40	20-A	40
SV 4	11 After 5 min or longer stir Record: pH 9.7 (8.0 or above)			
	12 If necessary adj to pH 8.0 or above Assume 50% & Record: pH		7-D	
	13 Run in V-314 thru 20 mesh screen & stir 10 min			
	14 Run in V-304 in 1-3 min & stir 5 min			
	15 Record: pH 9.8 (10.5-11.5)			
	16 Flood to 82" & stop agitator			
	S 16 200 202 204 210 213 261 264			
	IN. 54 62 62 53 37 42 82			
	GAL. 3650 3670 3646 3684 3667 3654 3624			
	START 7:00 AM	FIN 1:30 PM	OPTR 86-	
	1:20 P.M.	2:30 P.M.	381	

NOTE:

- USE STATION # 2 ONLY
- DO NOT USE A-148-D EQUIPMENT