

OLD SOLDERING WIPING PADS

MATERIAL IDENTIFICATION

Solder pads were discontinued in 1970's but some old soldering pads may still be in circulation. If the pad had been in use prior to 1977, it may contain asbestos.

PERSONAL PROTECTIVE EQUIPMENT

1. Latex gloves

EQUIPMENT AND SUPPLIES

1. Amended water in spray bottles
2. Asbestos disposal bags
3. Asbestos encapsulate

SITE PREPARATION

(none)

WORK PROCEDURES

1. Wet down the pads with encapsulate or amended water.
2. Carefully place the pads in an asbestos disposal bag.