

# American Brakeblok.

Lets take a hypothetical customer wanting a set of brake shoes for a 1964 Mercury Comet, Station Wagon, 6 cylinder. There are four easy steps to determine the proper set numbers, first turn to the Comet listing, then find the 1964 models, after which you look for a 6 cylinder station wagon. You should now be able to determine the proper sets to be used on this particular model. The sets needed are \*B-243 9 x 2 1/2 Front and \*B-243 9 x 2 1/2 Rear.

The (\*) star indicates the set number B-243 is available both bonded and riveted through NAPA.

## SECTION II

### NUMERICAL LIST OF RELINED BRAKE SHOE AND DISC BRAKE SETS

| Set No. | Size           | III. No. | Application                                               | Set No. | Size       | III. No. | Application                                                 |
|---------|----------------|----------|-----------------------------------------------------------|---------|------------|----------|-------------------------------------------------------------|
| B-1     | 9 x 2          | 56       | Nash 49, Stude. 47-53; Stude. Trk. 51-53; Volvo 56-59     | B-48    | 12 x 2-1/2 | 269      | Chry. 56; Des. 56; Imp. 56                                  |
| B-2     | 11 x 2         | 167      | Checker 48-62; K-F 49-50, Stude. 47-53; Stude. Trk. 48-54 | B-49    | 12 x 2-1/2 | 270      | Chry. 57, Des. 56; Imp. 56                                  |
| B-2C    | 11 x 2         | 168      | Stude. Trk. 48-56                                         | B-50    | 12 x 2-1/2 | 271      | Chry. 57-59, Des. 57-59; Dod. 57-59; Imp. 57-59; Ply. 57-59 |
| *B-7R   | 12 x 1 1/8 x 2 | 288      | Stude. Trk. 57-64                                         | *B-51   | 9 x 2      | 59       | Har. Da. 50-64; Hud. 53-54, IHC 61-62                       |
| B-8R    | 13 x 2-1/2     | 294      | Stude. Trk. 51-64                                         |         |            |          |                                                             |

| Set No. | Size | III. No. | Application                                                                                  | Set No. | Size | III. No. | Application                                                    |
|---------|------|----------|----------------------------------------------------------------------------------------------|---------|------|----------|----------------------------------------------------------------|
| S-702   | Disc | 1        | B.M. W59-60; Daimler 63; Rover 64-65, Austin 61-65; Jaguar 61-68; Mercedes 63-64; M.G. 59-60 | S-734   | Disc | 28       | Mercedes 63-66; Opel 63-66; BMW 65-66;                         |
| S-703   | Disc | 2        | Jaguar 58-62;                                                                                | S-735   | Disc | 29       | Opel 65-68; Porsche 64-65                                      |
| S-704   | Disc | 3        | Austin 59-62;                                                                                | S-736   | Disc | 30       | Simca 65-67; BMW 63-66; Mercedes 63-65, Opel 63-69; Porsche 64 |
| S-705   | Disc | 4        | Triumph 59-62;                                                                               | S-742   | Disc | 31       | Mercedes 65-66                                                 |

The numerical section is a list of all the Relined Brake Shoe and Disc Brake sets available through NAPA.

This section gives part number, size, illustration number and the various applications where each set is used.