

INDUSTRIAL HYGIENE VCM SAMPLING SHEET

Plant Name or Number	Bldg. No.	Sampling Equipment (other than OVA) Bendix Micro Air Pump	Flow LPM	Sampling Time ON OFF	OVA Readings	Name / Job Classification	Type of Filter Chargas	WEARING Respirator (Check One) ✓ None Air Cart.	OVA Number II	Background reading (ppm) 3
Filter No. Q-1	Pump No. 2	1.0	8:49 AM	8:59 AM	8 7 6 12	Maint. Coord.			Setting up AIR Line	Bill
Q-2	10	1.0	8:53 AM	9:02 AM	7 7 10	Helper			Filling #15 with water	Bill
Q-3	9	1.0	8:55 AM	9:02 AM	7 50 13 15	Chg OPER			Charging #'s 14 & 15	Bill
Q-4	H-1	1.0	8:59 AM	9:12 AM	7 6 8	Rec. OPER			Placing 42 & 43 on recovery	Bill
Q-5	2	1.0	8:59 AM	9:16 AM	14 10 15	HRC OPER			Prepares for HRC	
Q-6	10	1.0	9:06 AM	9:16 AM	13 15 10	Utility OPER			22 & 23 Polys Bill	
Q-7	9	1.0	9:11 AM	9:21 AM	7 7 7	Helper			Removing Head #22 Poly Bill	
Q-8	H-1	1.0	9:18 AM	9:28 AM	7 10 11 6	Foreman			Filling 42 & 43 with water Bill	
									Showing Helper Proper way to fill Poly with water	Bill

Signature *[Signature]* Date 8-21 1974
Supervisor Signature *[Signature]* Date 8/21/74