

BRAKE DRUMS (Cont.)

WHEREVER TWO DIFFERENT NUMBERED BOLTS AND NUTS ARE SHOWN FOR AN APPLICATION THE TOP LISTINGS ARE THE RIGHT HAND THREADS.

Car & Year	Models	Front Drums	Front Bolt	Qty.	Front Nut	Qty.	Rear Drums	Rear Bolt	Qty.	Rear Nut	Qty.
DODGE TRUCK (Cont.)											
1963-68	100A, Compact, 10" x 2-1/2" Brakes - Budd Type	3-2495	3-1678 3-1679	5 5	GP1012 GP1013	5 5	3-2908	3-1698 3-1699	5 5	GP1012 GP1013	5 5
1961-68	100W, 4 W.D. Budd Type	3-2905	3-1662 3-1663	8 8	B1012 B1012L	8 8	3-2939	3-1688 3-1657	8 8	B1012 B1012L	8 8
1959-65	All 1/2 Ton (Ex. 61-64 w/4 Wheel Drive)	3-2430†	3-1678 3-1679	5 5	GP1012 GP1013	5 5	3-2429†	3-1678 3-1679	5 5	GP1012 GP1013	5 5
1961-63	100, Conventional D Before Ser. 1430000	3-2430†	3-1678 3-1679	5 5	GP1012 GP1013	5 5	3-2429†	3-1678 3-1679	5 5	GP1012 GP1013	5 5
1957-58	All 1/2 Ton	3-2429†	3-1678 3-1679	5 5	GP1012 GP1013	5 5					
EDSEL											
1960	All (Ex. S.W.)	3-2590	3-1677	10	B1012	10	3-2569	A9A-1107A	10	B1012	10
1960	Station Wagon	3-2557	3-1677	10	B1012	10	3-2569	A9A-1107A	10	B1012	10
1959	All	3-2590	3-1677	10	B1012	10	3-2425	A9A-1107A	10	B1012	10
1958	Station Wagon	3-2590	3-1677	10	B1012	10	3-2425	A9A-1107A	10	B1012	10
1958	All Corsair & Citation (Ex. S.W.)	3-2499	3-1677	10	B1012	10	3-2591	A9A-1107A	10	B1012	10
1958	All Ranger & Pacer	3-2598	3-1677	10	B1012	10	3-2591	A9A-1107A	10	B1012	10
F-85											
1965-68	Vista Cruiser	3-2411	3-1689	10	358501	10	3-2438♦	3-1672	10	358501	10
1967	All (Ex. Vista Cruiser, H.D. Police)	3-2411	3-1689	10	358501	10	3-2412 or 3-2414♦	3-1734	10	358501	10
1964-66	All, Jetstar 88, Vista Cruiser (Ex. Vista Cruiser Rear, H.D. Police)	3-2411	3-1689	10	358501	10	3-2412 or 3-2414♦	3-1672	10	358501	10
1961-63	All (Ex. H.D. Brakes)	3-2566	3-1689 3-1690	4 4	358501 3-1772	4 4	3-2567	3-1729 3-1730	4 4	358501 3-1772	4 4
FAIRLANE											
1966-68	All 6 Cyl. & 8 Cyl. w/289 Eng. 10" x 2" Brakes						3-2440+	3-1693	10	B1012	10
1966-68	All w/390 Eng.; Station Wagon, Ranchero w/289 Eng. - Cast Front	3-2465+♦	3-1688	10	B1012	10	3-2487+	3-1693	10	B1012	10
1966-68	Station Wagon Model 71, 390 Eng. w/10" x 2-1/2" Brakes - Cast Front	3-2465+♦	3-1688	10	B1012	10	3-2487+	3-1693	10	B1012	10
1966-68	All 6 Cyl. & Models 54, 62, 63, 76; 8 Cyl. 289 Eng. 10" x 1-3/4" Brakes						3-2593	3-1693	10	B1012	10
1966-68	All 6 Cyl. & 8 Cyl. 289 Eng. (After 12/6/65) - Cast Frt.	3-2431+	3-1688	10	B1012	10					
1966-68	All Models 71 Sta. Wgns., 76 Conv., 66 Rancheros w/289 Eng.	3-2465♦	3-1688	10	B1012	10	3-2440+	3-1693	10	B1012	10
1966-67	All 6 Cyl.						3-2440+	3-1693	10	B1012	10
1966-67	All Models 54, 62, 63 w/8 Cyl. 289 (Hvy. Duty)						3-2440+	3-1693	10	B1012	10

* Original car manufacturer equipped these vehicles with 3 types of Brake Drums: these were all cast or composite (some smooth and/or ribbed). It is IMPORTANT that you check and identify the drum you are removing BEFORE ordering a Brake Drum for the specific application.

† Inboard Mounted.

♦ Drums have Ribbed Cooling Fins.