



Reduction Recommendations for this Soft Paste White Lead

NEW WORK—Soft Wood	FIRST COAT	SECOND COAT	THIRD COAT
White Lead	100 Pounds	100 Pounds	100 Pounds
Pure Raw Linseed Oil	4 Gallons*	1½ Gallons*	3 Gallons*
Pure Turpentine	1¾ Gallons	1¼ Gallons	
Drier	1 Pint	1 Pint	1 Pint
Makes	9 Gallons	6 Gallons	6¼ Gallons
*If Boiled Linseed Oil is used omit Drier.			
REDUCING TABLE FOR 12½, 25 AND 50-POUND PACKAGES			
50 pound Kegs—Divide the above quantities by 2			
25 pound Kegs—Divide the above quantities by 4			
12½ pound Kegs—Divide the above quantities by 8			

IMPORTANT • • READ

Important Note—Do not spoil the high quality by mixing with it cheap oil and cheap drier. USE 7

Add the oil a little at a time and stir in each

Resinous Wood—Reduce as directed above except have larger percentage of Pure Turpentine.

Previously Painted Surfaces—When in good condition directed above for second and third coats.

Unpainted Old Weathered Lumber—Reduce first coat should have larger percentage of Pure F

Since conditions and surfaces vary, no definite s

Flat Finish—For flat finish on interior walls contents of 100 pound pail with two gallons of F

Caution—Allow each coat to dry. In all painting each coat to dry before applying another. Inside v twenty-four hours and outside work two or three