

CENTRAL RESEARCH AND DEVELOPMENT DEPARTMENT
HASKELL LABORATORY FOR TOXICOLOGY
AND INDUSTRIAL MEDICINE

cc: C. F. Reinhardt/B. C. McKusick
H. M. Loux
R. J. Geisen
C. Miller, Jr. C-00827
M. McLaughlin

March 8, 1979

INTERIM HANDLING PROCEDURES FOR ASBESTOS

Before beginning the removal of asbestos, do the following:

1. Work Area should be designated "Limited Access Area," should be roped off and appropriate signs, conforming to Engineering Standard S-4-T, 7.6, shall be posted at all approaches. The Access Area will have a controlled Entry/Exit location with a Sign-In/Out Log Sheet used to record the names and times of persons entering/exiting the area.
2. All asbestos insulation to be removed will be wetted down first. Use a knife to remove, wherever possible, instead of a saw.
3. Do not bring food or cigarettes into the area, nor consume any food or smoke in the area.
4. While removing the asbestos insulation, take care not to drop it. Promptly place the waste in a sealed impermeable bag which has a caution label as to contents.
5. Respiratory protection will be provided to all personnel where the permissible exposure limits may be exceeded.
6. Special clothing -- Tyvek® suits with hood and foot coverings will be worn by employees who may be exposed to concentrations which exceed the limits.
7. Air sampling may be conducted while employees are removing asbestos-contained materials to determine airborne concentrations.

599

DUP 0904773

SC-DP-05800