

THE QUICK EASY WAY TO



FILL IT.
FIX IT.
PATCH IT!

TEXOLITE SPACKLING PUTTY

U.S. G.

FOR FINE PATCHING

TEXOLITE SPACKLING PUTTY

DIRECTIONS

SURFACE PREPARATION: Surfaces should be clean, free from loose particles, grease and dirt. Remove dirt, grease and oil with kerosene or turpentine. Wash with water and scrub with wire brush. Dry thoroughly. Fill with putty. Place over woodwork of joints.

APPLICATION: Put in a clean dish. Use up to 1/2 of a pint (16 oz.) of a mixing cup of putty for each pound of powder. Study and powder two water used mix into a smooth paste. Stirry more water until desired consistency is reached for a few seconds.

TEXOLITE SPACKLING PUTTY

This handy man's helper can help you boost profits because nearly everyone has need for TEXOLITE® Spackling Putty. Makes quick work of nail holes, knot holes, small cracks . . . fixes a hundred other

blemishes. Dealers say it sells itself, increases store traffic. And painters like the way it speeds surface preparation. Get to know the entire TEXOLITE Family . . . it's a great team for better business.

®TEXOLITE is a registered trademark which distinguishes the paint products manufactured only by the United States Gypsum Company



United States Gypsum

For Building • For Industry

Gypsum • Lime • Steel • Insulation • Roofing • Paint