

CG 03 CODE KY-907-D
 LOT 38054
 DATE 11/24/82

THIS IS A PROCEDURE TO
 REWORK A BATCH OF OVER-
 STEARATED KY-907-D BY
 WET MIXING WITH KY-795-D.
 JOB NAME: 907 REWORK

WAREHOUSE REQUEST

TIME 7:00 AM

CG	CODE	PQ	LOT	LBS
03	KY907D	98	37460	4129
03	KY795D	93	829171	1200 3400

TOTAL EST'D WGT 6529

NON-BLEEDING

EQUIP	NAME : "KROLOR" YELLOW MEDIUM	USE LBS	NCODE	ACCT LBS
ALM	1 CLOSE 2 ALM OUTLET			
	2 CLEAN 2 ALM MAGNETIC SEPARATOR & PUMP STRAINER			
1	3 INSTALL DUST HOOD & BASKET			
	4 RUN IN 4000# WATER			
	5 DUMP IN APPROX 2000# KY-907-D, 37460			
	NOTE: THIS MATERIAL IS IN RANDOM WEIGHT DRUMS. TWO SET-UPS IN ALM ARE NEEDED. TOTAL WEIGHT ON LOT IS 4129#. USE HALF (ABOUT 2000#) IN EACH SET-UP.			
	6 DUMP IN 1200# KY-795-D, 82917-1			
	7 STIR 60 MIN OR LONGER TO WET IN			
	RECORD: START <u>1:10AM</u> FINISH <u>2:10AM</u>			
SV	8 RUN IN 10" (1000GAL) WATER			
2	9 PUMP IN 2 ALM. RINSE IN WITH MIN WATER			
	10 START AGITATOR WHEN SLURRY COVERS BLADE			
	<i>added as per F.P. to add pump</i>			
ALM	11 CLOSE OUTLET			
	12 INSTALL DUST HOOD & BASKET			
3	13 RUN IN 4000# WATER			
	14 DUMP IN APPROX 2000# KY-907-D, 37460			
	NOTE: THIS SHOULD COMPLETE BATCH			
	15 DUMP IN 1200# KY-795-D, 82917-1			
	16 STIR 60 MIN OR LONGER TO WET IN			
	RECORD: START <u>3:45pm</u> FINISH <u>4:45pm</u>			
SV	17 PUMP IN 2 ALM. RINSE IN WITH MIN WATER			
18	DO NOT STOP AGITATOR			

START

11:45 AM
5:00 PM

FINISH

4:45 PM
9:15 PM

OPERATOR

11/24
54

N34894