

STEERING IDLER ARM REPAIR KITS (Cont.)-174

Car	Years	Models	Nylon Bushing	Steel Spring	Rubber Bushing
NASH	52-57	40, 50, 60, 80 Series	-----	-----	3-5810
	52-55	40-60 Series	-----	3-5809	-----
	49-52	60-40 Series	-----	3-5809	-----
	49-51	40-60 Series	-----	-----	3-5810
	41-49	Ambassador	-----	3-5809	-----
OLDSMOBILE	46-60	All	-----	3-5809	3-5810
PACKARD	42-50	Clipper and 1953 w/Power Steering	-----	3-5809	3-5810
PLYMOUTH	55-56	All	-----	-----	3-5811
	54-56	All	-----	3-5809	-----
PONTIAC	40-62	All	-----	3-5809	3-5810
RAMBLER	58-61	All	-----	3-5809	-----
	50-57	All	-----	3-5809	3-5810
TEMPEST	1962	All	-----	-----	3-5810
	1961	All	-----	3-5809	3-5810
THUNDERBIRD	58-60	All w/o Power Steering	-----	-----	3-5811

BUSHING PULLERS-174

(For Use in Pulling Bushings from Idler Arms Prior to Installation of Kits.)

Car	Years	Models	Part No.
CHEVROLET	55-57	All	3-5863
COMET	60-63	All	3-5863
EDSEL	58-60	All	3-5860
FALCON	60-63	All	3-5863
FORD	54-60	All	3-5860
MERCURY	54-56	All	3-5860
THUNDERBIRD	61-63	All	3-5863
	55-60	All	3-5860

