

BONDED BRAKE SHOE SETS

WITH *American
Brakeblok*®

® FRICTIONEERED FOR POWER OR STANDARD BRAKES

Part No.	FMS Shoe	Size	Part No.	FMS Shoe	Size
MERCURY—(Also see COMET)					
B-292B	55	11 x 1 3/4	B-2025C	126	11 x 2 1/2
B-1167	38	12 x 1 3/4	B-2055	16 or 125	11 x 3
B-1167A	37	12 x 1 3/4	B-2055A	125	11 x 3
B-2006	10	11 x 2	B-2080 (Can be used for B-2081)	126	11 1/32 x 2 1/2
B-2025A	13	11 x 2 1/2	B-2081	126	11 1/32 x 2 1/2
			B-2083	125	11 1/32 x 3

Original equipment shoes on 1961 cars have deeper indents on rim than shoes on 1960 models.

Year	Model or Series	Application	
		Front	Rear
1961	All Passenger	B-2080	B-2081
1961	Station Wagon	B-2083	B-2080
1960	All	B-2055A	B-2025C
1959-58	All (exc. Medalist)	B-2055	B-2025A
58	Medalist	B-2025A	B-2006
1957	All (exc. Sta. Wagon & TP Cruiser)	B-2025A	B-2025A
1957	Sta. Wagon & TP Cruiser	B-2055	B-2025A
1956-55	All	B-2025A	B-2006
1954-49	All	B-2006	B-292B
1948-46	All	B-1167A	B-1167A
1942-39	All	B-1167	B-1167

B-2080 can be used for B-2081.

METROPOLITAN—(Nash)

B-897	348 R & L	8 x 1 1/4	B-897B	360	8 x 1 1/4
B-897A	349	8 x 1 1/4	B-897C	361	8 x 1 1/4
1960-59	Metropolitan (After Serial #E-2284)		B-897B		B-897C
1959-55	Metropolitan		B-897		B-897A
1954	541, 542		B-897		B-897A

MG

B-817	325	9 x 1 15/32
B-841A	330	10 x 1 3/4

1955-50	TF & TD Midget	B-817	B-817
1957-54	Magnette, ZA, MCA	B-841A	B-841A

MOBILIFT—(Lift Trucks)

B-2006	10	11 x 2
B-2015A	18	11 x 2 1/4

1953-47	Models E, ER	B-2006
1954-47	Models H, HR, K	B-2015A

MORRIS

B-817	325	9 x 1 15/32
B-834	328	7 x 1 3/16
B-834A	329 R & L	7 x 1 3/16
B-841A	330	10 x 1 3/4

1959-55	Oxford series 11 & 111	B-817	B-817
1959-56	Cowley 1500	B-817	B-817
1956-55	Oxford	B-841A	B-841A
1957-49	Minor	B-834	B-834A