



Emergency Brake Lining Sizes

Year	D.D	Size W x Th. x Length	No Pcs	Cal No	Type
SOUTHERN COACH					
60-63	F31M, F35M, F31H, F35H, F31HF, F41H, S36M, S41M, S45MF, R37M.....16	3x1/4x90°.....4	S-557	Tru-Stop	
62-63	S45H, S41H, S41HF & S36DH112	4x1/4x11-3/8 & 12-7/81 ea.	2020	Internal	
63-63	S45DHC, S50DHC12	5x1/4x11-3/8 & 13-7/8.....1 ea.	2021	Internal	
STUDEBAKER					
1962	7E13, 7E28, 35, 40, 45.....9-1/2	2-1/2x3/16x271		S w/R L	
1962	7E28, 35, 40, 451	2-1/2x5/16x271		S w/R L	
66-62	E13, E14, E16, E28, E40, 1954 3R15, 16, 28, 17, 38; 1949-53, 2R14; 1952-53, 2R16 & B, 2R17A & B8	2-1/2x5/32x12-3/82	5419	External	
61-64	3R14, 2R15.....9-1/2	3x5/16x13-11/162	667	External	
1955	E13-15-16-17-28-38	2x5/16x24-5/8		S w/R L	
60-64	3R16, 3R28, 2R16 A & B, 3R17, 3R38, 2R17A & B, 2R17; 1956 E38; 1962 7E2811	2x1/4x90°.....2	S-576	Tru-Stop	
1962	7E28 & 40.....12	2-1/2x1/4x90°.....2	S-542	Tru-Stop	
1962	7E35 & 45.....9-1/2	3x5/16x14-1/22	103013	External	
SUPERIOR BUS					
60-65	SG6104, SG6105 & 06, City Avenue & Schooliner14-15	2-1/2x1/4x90°2	S-559	Tru-Stop	
60-63	SG706, 7306, 6703 & 4 & 7304-516	3x1/4x90°2	S-557	Tru-Stop	
TRANSCOACH					
60-62	CTR, DTR, TR8-404, TR404, TR45014-15	2-1/2x1/4x90°2	S-559	Tru-Stop	
WARD LAFRANCE					
65-67	Various models11	2x1/4x90°2	S-576	Tru-Stop	
63-63	Various models12	2x1/4x90°2	S-542	Tru-Stop	
61-63	Various models14-15	2-1/2x1/4x90°2	S-559	Tru-Stop	
60-67	Various models16	3x1/4x90°2	S-557	Tru-Stop	
WHITE BUS & TRUCK					
60-68	WC14, WC168	2-1/2x1/4x11-1/82	6021	External	
60-68	WC28-28T-32, WC2864-3264, WC24PLT .. .8	3x1/4x90°2	S-557	Tru-Stop	
60-68	1140, 1140S14-15	2-1/2x1/4x90°2	S-559	Tru-Stop	
60-68	WC16T, WC18-18T, WC20-20B-20T, WC 22-22T-26-26T, WC2264, 3016, 3016T, 3018, 3018T, 3020, 3022, 3022T, 30269-1/2	3x5/16x14-1/22	103013	External	
60	3016 (some)8	2-1/2x5/32x12-3/82	5419	External	