

CG 18 CODE GT-674-D

PKG.

EST. WGT.

2308

LBS.

STD. HRS.

TIME

M

7AM

PROCESSES		APPROVED BY	
() GT-674-D	(Y)	AJC	1-16-78
() GT-680-P	(K)	DCG	1-18-78
(A) GC-3-A	()	MTW	1-24-78
()	()		
TYPED BY			
NSA 3-22-78			

LEAVE ONE STUMP ONLY

CLEAN UP
AS YOU GO ALONG
NON-BLEEDING

IPMENT	NAME: MONASTRAL® GREEN B	USE LBS.	N CODE	ACCT. LBS.
SV	1 Run 2-3" (±200G) water into V- 264			
1	2 Use station # 2, preset water meter per chart for water addition to full totes. Use Mode 3 for N-8101-A full totes & mode 2 for stumping totes. When 8104-A scheduled, use mode 4 for pumping full totes & mode 1 for stumping tote. Pump in thru 20-mesh screen		8101-A	2180
	Gals of Water			
	Sequencer Steps			
	LOT 6 11 16 #100% %			
	811 540 30 50 213 22.2 959			
	808-B 40 30 50 710 36.8 2700			
	792-C 40 30 50 669 26.4 2535			
	816-C 40 30 50 588 23.5 2500			
	2180 #100% Total			
	3 Turn on agitator, use station # & pump in		8600-A	40
	LOT #100% %			
	200-A 40 19.5 205			
	4 After last tote pumped run in 100 gal water & pump to SV to clean line			
314	5 Run 18" (140 G) water into V-314 & heat to 80-100°F			
2	6 Turn on agitator & add in 2-3 min	125	530-A	125
	7 Stir 5 min & Record: pH 10.0 (10.0-10.5)			
	8 Stir 15 min or longer to dissolve for S 13			
304	9 Run 8" (98 G) water into V-304 & start agitator			
3	10 Add in ± 1 min & stir to dissolve for S 14	40	20-A	40
SV	11 After 5 min or longer stir Record: pH 9.0 (8.0 or above)			
4	12 If necessary adj to pH 8.0 or above Assume 50% & Record: pH		7-D	
	13 Run in V-314 thru 20 mesh screen & stir 10 min			
	14 Run in V-304 in 1-3 min & stir 5 min			
	15 Record: pH 9.3 (10.5-11.5)			
	16 Flood to 82" & stop agitator			
	S 16 200 202 204 210 213 261 264			
	IN. 54 62 62 53 37 42 82			
	GAL. 3650 3670 3646 3684 3667 3654 3624			
	START FIN OPTR			
	11: 3:00 AM 301			

