

534-STARTER END PLATES (Cont.)

Make	Years	Models	Drive End Plate	Commutator End Plate
MERCURY (Cont.)	59-61	All	—	3-1318
	56-58	All	3-1319	3-1318
MUSTANG	65-68	All 8 Cyl. & 6 Cyl. 200" (Ex. w/4" Starter)	—	3-1320
	1965	6 Cyl. 170"	—	3-1321
NASH	1957	All Ambassador 8 Cyl.	—	3-1317
	1956	All Ambassador w/ST & HM	—	3-1322
	1956	All Stat. 8 Cyl.	—	3-1317
OLDSMOBILE (See F-85)	54-68	All	—	3-1317
PACKARD	57-58	All	—	3-1317
	55-56	All A.L.	—	3-1322
	55-56	All D.R.	—	3-1317
PLYMOUTH (See Valiant)	1961	All 6 Cyl.	—	3-1324
	1960	All (Ex. Canada)	—	3-1324
	1960	All Canada (Ex. Late w/8 Cyl.)	—	3-1323
	57-59	All	—	3-1323
	1956	All w/PF & ST	—	3-1322
PONTIAC (See Tempest)	55-68	All	—	3-1317
RAMBLER	63-68	All	—	3-1317
	1963	All 6 Cyl.	—	3-1317
	61-62	All 6 Cyl. (Ex. American)	—	3-1317
	60-62	All 8 Cyl. (Ex. D.R.)	—	3-1324
	60-62	American w/6 Cyl.	—	3-1324
	59-62	All D.R. 6 & 8 Cyl.	—	3-1317
	60-61	All 8 Cyl. & American 6 Cyl.	—	3-1324
	56-58	All	—	3-1317
STUDEBAKER	62-64	All	—	3-1324
	60-61	All (Ex. 8 Cyl.)	—	3-1324
	59-61	All (Ex. 6 Cyl.)	—	3-1317
	56-58	All (Ex. 6 Cyl.)	—	3-1317
	1956	All Golden Hawk	—	3-1322
STUDEBAKER TRUCK	62-64	All 8 Cyl.	—	3-1324
	61-64	All 6 Cyl.	—	3-1324
	56-61	All 8 Cyl.	—	3-1317
	58-60	All 6 Cyl.	—	3-1323
	56-58	Big 6	—	3-1317
TEMPEST	61-68	All (Ex. 61-62 8 Cyl.)	—	3-1317
	61-62	All (Ex. 4 Cyl.)	—	3-1325
THUNDERBIRD	65-68	All (Ex. w/4" Starter)	—	3-1320
	62-64	All	—	3-1318
	56-61	All	3-1319	3-1318
VALIANT	60-61	All	—	3-1324
WILLYS	63-65	O.H.C. Eng. 12 Volt	—	3-1324
	61-65	All 12 Volt, 4 Cyl.	—	3-1324
	61-63	All 12 Volt 6 Cyl.	—	3-1324
	59-60	All 12 Volt, 4 & 6 Cyl.	—	3-1317
	58-60	All 12 Volt L6-226	—	3-1323