


PARTS LIST

574—Follower	806—Lock Washer
654—Connection	807—Connection
674—Fulcrum Bracket	808—Block
676—Bracket	809—Spring Seat
677—Pin	810—Spring
801—Bracket	811—Spring
802—Adapter	812—Set Screw
803—Bushing	813—Lever
804—Bell Crank	925—Jam Nut
805—Shoulder Bolt	946—Jam Nut
948—Jam Nut	



Note:—Pressure governor construction details and replacement parts list furnished by manufacturer. Give serial number when requesting information.

FIG. 13—BUILT-IN CONSTANT PRESSURE PUMP GOVERNOR

X-612960
X-612966
X-612970A