



# PUSHBUTTONS and LIGHTS

195






## Type T—Oil Tight

### ASSEMBLED CONTROL STATIONS

### MAXIMUM AMPERE RATINGS

| No. of Elements | Type of Elements                     | Feature                                                              | Symbol | Legend                                                            | Surface Mtg.                     |                  | Flush Mtg.                       |                  |
|-----------------|--------------------------------------|----------------------------------------------------------------------|--------|-------------------------------------------------------------------|----------------------------------|------------------|----------------------------------|------------------|
|                 |                                      |                                                                      |        |                                                                   | Catalog No.                      | Price            | Catalog No.                      | Price            |
| One             | Push-button                          | Standard                                                             |        | Start Stop                                                        | 10250-H3516<br>H3518             | \$16.16          | 10250-H3573<br>H3575             | \$12.12          |
|                 |                                      | Mushroom Head                                                        |        | Start Stop                                                        | H3517<br>H3519                   | 19.19            | H3574<br>H3576                   | 15.15            |
|                 |                                      | With Lock Hasp                                                       |        | Stop                                                              | H3520                            | 19.              | H3577                            | 15.              |
|                 | Selector Switch                      | 2 Position                                                           |        | Start-Stop Off-On                                                 | H3521<br>H3523                   | 17.17            | H3578<br>H3580                   | 13.13            |
|                 |                                      | 3 Position Spring Return from Left                                   |        | Start-Stop                                                        | H3522                            | 19.              | H3579                            | 15.              |
|                 |                                      | 3 Position                                                           |        | Man-Off-Auto                                                      | H3524                            | 17.              | H3581                            | 13.              |
| Two             | Push-buttons                         | Standard                                                             |        | Start-Stop Raise-Lower                                            | H3525<br>H3672                   | 23.23            | H3582<br>H3673                   | 18.18            |
|                 |                                      | With Lock Hasp                                                       |        | Start-Stop                                                        | H3527                            | 26.              | H3584                            | 21.              |
|                 |                                      | Standard and Mushroom Head                                           |        | Start-Stop                                                        | H3526                            | 26.              | H3583                            | 21.              |
|                 |                                      | Standard with Maintained Contact Attachment                          |        | Start-Stop                                                        | H3528                            | 23.              | H3585                            | 18.              |
|                 | Selector Push-button and Push-button | Roto-Push® and Standard                                              |        | For-Safe-Rev., Stop High-Low, Stop                                | H3529<br>H3531                   | 29.29            | H3586<br>H3588                   | 24.24            |
|                 |                                      |                                                                      |        | Run-Safe-Jog, Stop                                                | H3530                            | 26.              | H3587                            | 21.              |
| Three           | Push-buttons                         | Standard                                                             |        | For., Rev., Stop High, Low, Stop Up, Down, Stop Open, Close, Stop | H3532<br>H3533<br>H3615<br>H3614 | 31.31.<br>31.31. | H3589<br>H3590<br>W81<br>W82     | 25.25.<br>25.25. |
|                 |                                      | 2 Standard and With Lock Hasp                                        |        | Open, Close, Stop                                                 | H3616                            | 34.              | W83                              | 28.              |
|                 | Selector Switch and Push-buttons     | 2 Position and Standard                                              |        | For-Rev, Start, Stop Run-Jog, Start, Stop                         | H3534<br>H3535                   | 32.32.           | H3591<br>H3592                   | 26.26.           |
|                 |                                      |                                                                      |        | Motor Run, Start, Stop                                            | H3536<br>H3537<br>H3538<br>H3539 | 36.36.<br>36.36. | H3593<br>H3594<br>H3595<br>H3596 | 30.30.<br>30.30. |
|                 | Indicating Light and Push-buttons    | Red lens—110V.<br>Red lens—220V.<br>Red lens—440V.<br>Red lens—550V. |        |                                                                   |                                  |                  |                                  |                  |

| Volts                        | A-C |     |     |     |
|------------------------------|-----|-----|-----|-----|
|                              | 110 | 220 | 440 | 550 |
| Make & Interrupting Capacity | 60. | 30. | 15. | 12. |
| Normal Load Break            | 6.  | 3.  | 1.5 | 1.2 |
| Continuous Current           | 10. | 10. | 10. | 10. |
| Volts                        | D-C |     |     |     |
|                              | 120 | 240 | 600 |     |
| Make & Interrupting Capacity | 2.2 | 0.5 | 0.2 |     |
| Normal Load Break            | 2.2 | 0.5 | 0.2 |     |
| Continuous Current           | 10. | 10. | 10. |     |



3 PHASE FULL VOLTAGE MOTOR CONTROL

3 PHASE REDUCED VOLTAGE & MULTISPEED MOTOR CONTROL

1 PHASE MOTOR CONTROL

AC-DC CONTACTORS, RELAYS & TIMERS

PUSHBUTTONS & LIGHTS, LIMIT SWITCHES, FOOT SWITCHES

MISCELLANEOUS ACCESSORIES & COMPONENTS