




Zeroing the Dial Indicator

13. Stop the lathe and rotate the mounting flange until the needle reaches the extreme high point of its sweep. The knob on the back of the motor can be used to manually crank the motor to the high point.