

36-Inch IDEAL WATER TUBE BOILERS

Sections and Parts Required

Oil and Stoker

STEAM AND WATER

SERIES 9-B

Complete Boiler Consists of Following Units:	No. of Units for Each Boiler					
	#0736	#0836	#0936	#1036	#1136	#1236
AO —Front Section—Steam or Water— Uncrated.....	1	1	1	1	1	1
BO —Front Center Section—Steam or Water—Uncrated.....	0	0	1	1	1	1
CTO—Center Section with Regulator Tap- ping—Steam or Water—Uncrated.....	1	1	0	0	0	0
CO —Center Section (Steam Assembly.... Uncrated (Water Assembly....	3 2	4 3	5 4	6 5	7 6	8 6
DO —Center Connecting Section with 2- 3 1/2" Return Tappings—Water Only— Uncrated.....	1	1	1	1	1	2
UO —Rear Center Uptake Section— Steam or Water—Uncrated.....	1	1	1	1	1	1
H —Back Section—Steam or Water— Uncrated.....	1	1	1	1	1	1
Front Door Crate (Contents listed on other side).....	1	1	1	1	1	1
Base Front Crate (Contents listed on other side).....	1	1	1	1	1	1
Smokehood Crate (Contents listed on other side).....	1	1	1	1	1	1
Plate Box (Contents listed on other side)...	1	1	1	1	1	1
Steam Trim Box (Contents listed on other side)..... —Or—	1	1	1	1	1	1
Water Trim Bag (Packed In Front Door Crate) (Contents listed other side)....						
Tie Rod Bundle.....	1	1	1	1	1	1
Flue Brush Handle.....	1	1	1	1	1	1
Base Side Panels:						
Left Hand.....	1 (36-WT-27)	1 (36-WT-28)	1 (36-WT-29)	1 (36-WT-30)	1 (36-WT-31)	1 (36-WT-31)
Left Hand Rear (*36-WT-54).....	0	0	0	0	0	1
Right Hand Front (36-WT-131).....	1	1	1	1	1	1
Right Hand Rear.....	1 (36-WT-136)	1 (36-WT-137)	1 (36-WT-25)	1 (36-WT-26)	1 (36-WT-27)	1 (36-WT-28)

*Included in 12-Sec. Plate Box.

NOTE: Code Letters are cast on head end of all sections. Other Units (crates, boxes and bundles) are marked for boiler size if not common to all assemblages.

See other side for Contents of crates, bags and boxes included in above list.

PLAINTIFF'S
EXHIBIT

01022

ASE-335