


 AMERICAN
STANDARD

2-GA


2-GA-E

standard gas boiler
Empire gas boiler
water only



series 12B & 13B

2-GA-4-E
2-GA-5-E
2-GA-6-E
2-GA-7-E



Cast iron repair parts for this boiler will be discontinued by series as follows.


series 12B - Dec. 31, 1969

series 13B - Dec. 31, 1974




Jacket parts for this boiler are no longer available. Pictures are shown for identification purposes only.

Repair part price for each part number is found at back of book.

cat. no.	description	part no.	series no.
1	assembling nipple, 2"	3072	12B & 13B
2	cleanout cover plate	2862	
3	front burner door frame	2850	7B to 13B
4	back burner door frame	2850	7B to 13B
5	front burner door	2852	7B to 13B
6	back burner door	2851	7B to 13B
7	manifold bracket	2829	7B
8	manifold bracket, L. H.	2863	8B to 13B
9	manifold bracket, R. H.	2864	8B to 13B
10	manifold pipe, all gases	6731	9B to 13B
11	orifice holder	6454	8B to 12B
12	orifice holder	6450	13B
*13	main burner orifice	7613	
*14	pilot burner 2D11-8	6968	11B to 13B
*15	pilot orifice for 2D11 burner (Nat.)	7644	11B to 13B
16	1/4" M x 1/2" straight tubing connector	5733	8B to 13B
17	burner support	2856	
18	air shutter, Nat. & Mixed, LP-air, LP and ribbon burner	77965	7B to 13B
19	air shutter, Mfd. gas, drilled port burner	79846	8B to 13B



* specify type of gas



40 - 41



42



44 - 47



48 - 50



51



52

2-GA standard & 2-GA-E

Empire gas boilers

note: parts are used for 12B & 13B
where series is not shown

cat. no.	description	part no.	series no.
burner, Mfd. gas:			
20	4 section	2804	
21	5 section	2807	
22	6 section	2810	
23	7 section	2813	
burner, Nat. & Mixed gas:			
24	4 section	2805	
25	5 section	2808	
26	6 section	2811	
27	7 section	2814	
burner, LP-gas:			
28	4 section	2806	8B to 13B
29	5 section	2809	8B to 13B
30	6 section	2812	8B to 13B
31	7 section	2815	8B to 13B
ribbon burner, Mfd. gas:			
32	4 section	2867	
33	5 section	2869	
34	6 section	2865	
35	7 section	2871	
mixing tube:			
36	4 section	2816	
36A	4 section - L.P. only	2817	
37	5 section	2818	
37A	5 section - L.P. only	2819	
38	6 section	2820	
38A	6 section - L.P. only	2821	
39	7 section	2822	
39A	7 section - L.P. only	2823	
canopy:			
40	4 section	2857	
41	5 section	2858	
42	6 section	2859	
43	7 section	2860	
draft hood:			
44	4 & 5 section Empire - 5" diameter	82732	
45	4 & 5 section Standard - 5" diameter	83076	
46	6 section Empire - 6" diameter	82733	
46A	7 section Empire - 6" diameter	94173	
47	6 section Standard - 6" diameter	83077	
47A	7 section Standard - 6" diameter	93360	
48	1/2" manual shut-off valve	5707	8B to 13B
49	3/4" manual shut-off valve	5691	8B to 13B
50	1" manual shut-off valve	5696	8B to 13B
51	pilot patrol filter	6138	8B to 13B
52	electric ignition transformer	7869	13B

Repair part price for each part number is found at back of book.

2-GA standard & 2-GA-E

Empire gas boilers

note: parts are used for 12B & 13B
where series is not shown

cat. no.	description	part no.	series no.
53	manual pilot bracket	82980	8B to 13B
54	1/4" x 1/4" union tubing connector	5737	8B to 13B
55	throttling pilot valve 1/4" M x 1/4" tubing connector	5683	8B to 13B
56	terminal block, 4 point	5105	8B to 13B
57	drain valve	5662	
58	vent tubing with tip	9144	8B to 13B
59	vent tube clip	5639	8B to 13B
60	split nut and packing gland	6829	8B to 13B
61	1/4" M x 1/4" elbow tube connector	5728	8B to 13B
62	runner pilot with push button valve and connector	6977	8B to 13B
63	runner pilot clamp (2 per set)	87499	8B to 13B
64	pilot patrol filter	6141	8B to 13B
65	terminal block, 5 point	5106	8B to 13B
66	1/4" tubing tee	7823	8B to 13B



53



54



55



56



59



60



61



62



63



64




65



66



500



501



502

sections >

cat. no.	description	part no.	series no.
*500	front section	4703	
501	back section	4705	6B to 13B
502	center section	4704	

* can be used as back section on series 4B & 5B