

AXLE SHAFT AND FRONT WHEEL LOCKNUTS (Cont.)

Car	Years	Models	Front Wheel	Axle
FORD TRUCK	48-65	All 1/2 & 3/4 Ton	3-4942	3-4941
	33-53	All (Ex. 1/2 & 3/4 Ton)	3-4945	-----
	19-29	TT, AA, 1 Ton	-----	3-4945
FORD TRACTOR	39-61	All	3-4942	-----
	39-59	All	-----	3-4940
FRAZER	47-53	All	3-4942	3-4946
GMC	55-65	2 Ton	3-4944	-----
	46-65	1/2 Ton	3-4943	-----
	46-65	3/4, 1, 1-1/2 Ton	3-4944	-----
	39-42	1-1/2 Ton	3-4942	-----
HUDSON	34-46	All	-----	3-4943
IHC	56-65	Light Duty	3-4942	-----
		All K1-K2-K3-Pick Up	3-4942	-----
		All K4-K5	3-4945	-----
	41-49	KS-3, COE, K-5	3-4946	-----
INTERNATIONAL FARMALL		A, Super A, B, C, Super C	3-4941	-----
JOHN DEERE		A, D, GR	3-4946	-----
		B, M, MT	3-4942	-----
KAISER	47-53	All	3-4942	3-4946
LANCER	61-62	All	3-4942	3-4945
LARK	1965	All	3-4942	-----
	59-64	All	3-4942	3-4945
LINCOLN	36-65	All	3-4942	-----
MACK		21AX15, ED, FA22	3-4942	-----
		21AX20	3-4946	-----
MASSEY-HARRIS		20, 30, 33, 44, Colt & Mustang	3-4945	-----
MINNEAPOLIS-MOLINE		MMV, BF	3-4942	-----
MERCURY (SEE COMET)	49-65	All	3-4942	-----
NASH (SEE RAMBLER)	50-57	Statesman	3-4942	3-4942
	54-57	Ambassador	3-4942	-----
	50-53	Ambassador	3-4942	3-4945
	41-50	4160, 4180, 4260, 4280, 4660, 4760, 4840, 4860, 4940, 4960, 5040, 5060	3-4942	-----
	32-46	1080, 1090, Big 8, 1180, 1190, 1220, 1280, 3520, 3580, 3620, 3680, 3640, 3720, 3740, 3780, 3820, 3840, 3880, 3920, 3940, 3980	-----	3-4945
OLDSMOBILE	57-64	All	-----	3-4939
	39-56	All	3-4943	-----
PACKARD	48-58	All	3-4942	-----
PLYMOUTH (SEE VALIANT)	1965	All	3-4942	-----
	46-64	All	3-4942	3-4945
PONTIAC (SEE TEMPEST)	47-65	All	3-4943	-----
	To 46	All	3-4942	-----
RAMBLER	58-65	All	3-4942	3-4945
	1957	All	3-4942	-----
STUDEBAKER	51-65	All (Ex. Commander & Lark)	3-4942	3-4945
	47-50	All (Ex. Commander & Lark)	3-4942	-----
	47-50	Commander Only	-----	3-4946
TEMPEST	61-65	All	3-4943	-----
VALIANT	1965	All	3-4942	-----
	60-64	All	3-4942	3-4945
WILLYS	To 46	All	3-4942	-----