



D-C CONTACTORS

Magnetic Non-Reversing

1 CONTACTOR MOUNTING KITS

Table 2

NEMA Size	Type of Mounting	For Metal Panels		For Insulated Panels	
		Catalog Number	③ Price	Catalog Number	② Price
3	② Surface, Front-of-Panel Wiring.....	6002--		6002--	
	Surface, Rear-of-Panel Wiring.....	H465		H474	
	Elevated, Front-of-Panel Wiring.....	H468	\$6.	H477	\$6.
4	② Surface, Front-of-Panel Wiring.....	H462		H471	
	Surface, Rear-of-Panel Wiring.....	H630	6.	H631	6.
	Elevated, Front-of-Panel Wiring.....	H468		H477	
5	② Surface, Front-of-Panel Wiring.....	H462		H471	
	Surface, Rear-of-Panel Wiring.....	H466	12.	H475	12.
	Elevated, Front-of-Panel Wiring.....	H469		H478	
6 and 810 Ampere	② Surface, Front-of-Panel Wiring.....	H463		H472	
	Surface, Rear-of-Panel Wiring.....	H467	18.	H476	18.
	Elevated, Front-of-Panel Wiring.....	H470		H479	
		H464		H473	

① Mounting kits include power studs and stud mounting as well as contactor mounting hardware.


② Lugs included.

③ Mounting Kit included in contactor price. Prices apply only when purchased separately.


AUXILIARY CONTACT UNITS

Table 3

Side Mounting Units for Size 1 and 2 Contactors				Bottom Mounting Units for All Contactors			
Contact Arrangement	Catalog Number	④ Price (Unit Only)	Price (Factory Installed)	Contact Arrangement	Catalog Number	④ Price (Unit Only)	Price (Factory Installed)
1 N.O.	10923-H6	\$6.	\$9.	1 N.O.	10923-H1	\$6.	\$9.
2 N.O.	H7	9.	12.	2 N.O.	H2	9.	12.
1 N.O.-1 N.C.	H8	9.	12.	1 N.O.-1 N.C.	H3	9.	12.
1 N.C.	H9	6.	9.	1 N.C.	H4	6.	9.
				2 N.C.	H5	9.	12.



Size 2
2 pole normally open



Size 4
1 Pole Normally Closed

AUXILIARY CONTACT MOUNTING KITS AND QUANTITY OF UNITS ACCEPTABLE PER CONTACTOR

Table 4

For Size and Type of Contactor		Location of Auxiliary Contacts on Contactor and Number of Units Kit Will Mount		Maximum Number of Units Acceptable per Contactor	Mounting KIT Catalog Number	Price
NEMA Size	Poles	Location	No. of Units			
1 and 2	1 N.O.	Bottom—Right and Left Side—Right or Left	2 1	2	10923-H11 H12	\$1.
	2 N.O.	Bottom—Right and Left Side—Left Only Side—Right Only	2 1 1	2	H14 H15 H16	
	2 N.O.—1 N.C.	Side—Left Only Side—Right Only	1 1	2	H15 H16	
3, 4 and 5	1 N.O.	Bottom—Left Only Bottom—Right and Left	1 2	2	H18 H19	1.
	⑤ 1 N.C.	Bottom—Right Only	1	1	H20	
6	1 N.O.	Bottom—Left Only Bottom—Right and Left	1 2	2	H18 H19	1.
	⑤ 1 N.C.	Bottom—Right Only	1	1	⑤	
810 Ampere	1 N.O.	Bottom—Left Only Bottom—Right and Left	1 2	2	H18 H19	1.

④ Unit only without mounting hardware. Order mounting kit by catalog number.

⑤ 10923H19 supplied with contactor as standard. No charge.

⑥ When auxiliary contact is mounted on normally closed contactor the unit is actuated when the contactor is in the normal or closed position. Therefore a N.O. contact will become N.C. and a N.C. circuit will become N.O.