

244-THERMOSTATIC HEATER CONTROL VALVES (Cont.)

HEATER VALVE APPLICATION CHART (Cont.)

Car	Years	Models	OEM No.	Part No.
DESOTO	60-61	All	2084461	3-1857
	1959	All	2084273	3-1851
	55-58	All w/Model 705 Heater	1819516	3-1832
	55-58	All	1688946	3-4413
	53-54	All w/Model 600, 601, 602, 603, 604, 605 Heater	1479841	3-1807
	49-54	All w/Model 103, 500, 501, 502, 503, 504, 550 Heater	1540547	3-1800
DODGE PASSENGER	67-68	Monaco w/Air Cond.	2521672	3-1866
	65-68	Polara w/Air Cond.	2521672	3-1866
	1967	Charger w/Air Cond.	2607027	3-1867
	66-67	Coronet w/Air Cond.	2607027	3-1867
	65-66	Coronet	2275592/2448674	3-1815
	1965	Coronet w/Air Cond.	2521672	3-1866
	62-64	880 w/Air Cond.	1972779	3-1857
	62-64	All w/Model 720 & 727 Heater	2275592/2448674	3-1815
	60-64	All w/Model 715 Heater	2084461	3-1857
	1962	All w/Model 719 Heater	2219280	3-1853
	61-62	Lancer	2219280	3-1853
	1959	All	2084273	3-1851
	55-58	All w/Model 705 Heater	1819516	3-1832
	55-58	All (Ex. w/Model 705 Heater)	1688946	3-4413
	53-54	All w/Model 600, 601, 602, 603, 604, 605 Heater	1479841	3-1807
	49-54	All w/Model 103, 104, 500, 501, 502, 503, 504, 505, 506, 550 Heater	1540547	3-1800
DODGE TRUCK	61-62	All (Ex. late '62) w/Model 83 Heater	1932796	3-1833
EDSEL	1960	All w/o Air Cond.	C0AF-18502E	3-1852
	1958	Citation & Corsair	B7A-18502B	3-1849
F-85	61-63	All	3152082	3-1814
FORD PASSENGER (See Thunderbird)	1962	All w/Air Cond.	C0AF-18502D	3-1852
	60-61	All	C0AF-18502D	3-1852
	57-58	All	FEK-18502A/B7A-18502B	3-1849
	52-56	All	B5A-18502A	3-4412
	50-51	All	1A-18502A	3-1800
	1949	All	8M-18502B	3-1831
FORD TRUCK	61-63	Econoline	C1UF-18502A/C3UZ-18502A	3-1861
	48-50	All w/Hot Water Heater	8M-18502B	3-1831
GMC TRUCK	62-63	All w/Tilt Cab	3149677	3-1820
	62-63	All & Including 3rd Series in 1961 (Ex. Tilt Cab)	3149596	3-1818
	60-61	All w/Tilt Cab	3147359	3-1817
	60-61	All Series 1 & 2 (Ex. Tilt Cab)	3146091	3-1819
	57-59	All	3138019	3-4411
	55-56	All	3134209	3-1859
HUDSON	49-57	All (Ex. Jet & Super Jet)	302628/306788/4386047	3-1800
IMPERIAL	1967	All w/Air Cond.	2521672	3-1866
	62-66	All w/Air Cond.	1972781	3-1857
	60-66	All	2084460	3-1857
	60-63	All	2096794	3-4418
INTERNATIONAL TRUCK	All	All w/Heater 184157R92	188561R91	3-1830
	All	All w/Heater 214031R91 & 217883R91	224556R91	3-1829